

GKM Series



GeKaMac®

Gas Shielded ARC Welding Machines



Model :

- GKM 240
- GKM 250
- GKM 350-G
- GKM 350-2G
- GKM 420-G
- GKM 420-2G
- GKM 420-W
- GKM 420-2W
- GKM 500-2W
- GKM 500-2G
- GKM 600-2W

Please Read and Understand This Manual
Before Operating The Welding Machine

www.gedikwelding.com



Attention!

Our Valued Customer,

We kindly request that you obey the warnings mentioned below:

- Definitely have the “Warranty Document” approved when you get the machine.
- Use the machine in a way that is in accordance with the fundamentals that are mentioned in the user’s guide of the machine.
- Refer to the nearest GEDIK WELDING authorized service or the service center of GEDIK WELDING when a problem comes up.

Thank you for preferring one of GeKaMac[®] products.

INDEX

	Page
1. Index	3
2. Safety Rules	4
2.1. Electrical Shock	4
2.2. Arc Rays	4
2.3. Gases and Fumes	4
2.4. Welding Sparks	4
2.5. Electricity and Magnetism	4
3. Electromagnetic Compatibility (EMC)	5
4. General Information and Warnings	6
5. Control Panels	7
6. Label Information	12
7. Technical information	14
8. Machine Set up Information	16
9. Machine Maintenance	16
10. Storage and Transportation	17
11. Gas Shielded Arc Welding Method	17
12. Gas Metal Arc Welding Machine Problems	18
13. Spare Parts	20
13.1. Spare Parts of GeKaMac® GKM 240	20
13.2. Spare Parts of GeKaMac® GKM 250	21
13.3. Spare Parts of GeKaMac® GKM 350-G, GKM 350-2G	22
13.4. Spare Parts of GeKaMac® GKM 420-W, GKM 420-G, GKM 420-2W	24
13.5. Spare Parts of GeKaMac® GKM 500-2W, GKM 500-2G	26
13.6. Spare Parts of GeKaMac® GKM 600-2W	28
14. Conditions of Warranty	30
15. Warranty Document	31

2. SAFETY RULES

Protect yourself and others against possible serious injury or death risks. Keep children away. People who have pacemakers in their bodies should consult their doctors before operating the welding machine. Be careful when you are doing operations with your hands on the pieces. Use proper equipment that are necessary to protect yourself from burns that can be caused by excessive heating of the piece during welding and / or cutting operation. Be sure that all set up, maintenance and repair related operations are performed only by qualified people.

2.1. ELECTRICAL SHOCK



The piece that is being worked on or ground circuits are active in terms of electricity while the welding machine is on. Don't touch these active parts with bare hands or wet clothing. Wear dry gloves that have no holes to insulate your hands.

2.2. ARC RAYS



Use a protective mask with a proper filter to protect your eyes from the sparks and the rays of the arc while welding or watching such an activity. The head mask and the filtered glasses must meet the ANSI Z87.1 standards.

2.3. GASES AND FUMES



Fumes and gases that are harmful to health can form during the welding operation. Do not inhale these gases or fumes. Keep your head out of the fumes while welding. Provide sufficient ventilation in the arc and / or use fume suction machines to keep fumes and gases out of the breathing area.

2.4. WELDING SPARKS



Put away elements that are fire hazards from the welding area. If this is not possible, cover these hazards to prevent welding sparks from starting a fire. Do not forget that welding sparks and hot materials coming from welding can go on to neighboring areas easily through small cracks and openings. Don't do welding near hydraulic lines. Always keep a fire extinguisher on hand.

2.5. ELECTRIC AND MAGNETISM



Electric flow that passes through a conductor causes Electric and Magnetic Fields (EMF) to be formed. Welding current creates EMF around welding cables and welding machines.

— EMF can ruin the operation of some pacemakers. For this reason, welders who have pacemakers in their bodies should consult their doctors before welding.

— Being exposed to EMF during welding, can cause other unknown health problems.

— Getting exposed to EMF will be minimized by paying attention to the following instructions:

- Guide earthing and chassis cables together.
- Never wrap electrode and chassis cables around your body.
- Do not place your body between the electrode and chassis cables.
- Connect the chassis cable as close to the piece that is being worked on as possible.
- Stay as far away as you can from the power units.

3. ELECTROMAGNETIC COMPATIBILITY (EMC)

This machine has been designed in accordance with all related regulations and norms. Additionally, it can still generate electromagnetic forces that affect other systems such as communications (telephone, radio, television). These affects can cause security problems in the exposed systems. Read carefully and understand this section in order to reduce or get rid of the affects that can be created by this machine.

This machine has been designed to be operated in the industry area. If it is operated in private places (house etc.), it will become necessary to take special precautionary measures in order to prevent possible electromagnetic affects. It is necessary for the user to set up and operate these machines just like the way it is described in the handbook. If an electromagnetic affect is perceived due to the operation of these machines, the user should take corrective measures in order to get rid of these affects. If necessary, the user should contact GEDIK WELDING IND. COM. LTD. CO. No changes should be made in the machine without getting written approval from GEDIK WELDING IND. COM. LTD. CO.

The control of the work area should be made in terms of tools that can work improperly due to the electromagnetic affects before the machine is assembled.

- Inlet and outlet cables, telephone cables and control cables that are found in the work area of the machine.
- Radio and/or television transmitters and receivers,
- Computer or computer controlled tools,
- Safety and control equipment for industrial operations,
- Calibration and measurement appliances,
- Medical appliances such as heart rhtyme appliance and hearing aids,

Control the electromagnetic immunity of the equipments that operate near the work area. The user should be certain that all the equipments that are in the work place are compatible. Otherwise, it can necessitate additional protective measures.

Ideal dimensions of the work place are determined by the construction of the area and other factors that are found there. Take the warnings below into consideration in order to decrease the affects of the electromagnetic waves that the machine generates:

* Make the connection of the machine with the network electricity in the way it is stated in the user's guide. If an electromagnetic interaction comes into being, such preventive measures as filtering the main electrical inlet may need to be taken.

* Outlet cables should be as short as possible and should be kept together.

4. GENERAL INFORMATION AND WARNINGS

Do not set up, operate or repair before reading the user's guide and the security measures that are found in it. Hide this user's guide and always have it on hand.

- Cut off the electrical connection between the welding machine and the network when the work is finished or when you are going to take a long break.
- Do not make any changes in the welding machine. This operation can cause the machine to lose its properties and a change in technical data.
- It is forbidden to do adaptation on the welding machine. Doing adaptation does not only cause the loss of warranty rights, but also can jeopardize the operational safety of the machine and can create the risk of electrocution for the users.
- A damage in the welding machine due to a mistake of the user will cause the loss of warranty rights.
- Acceptable environmental temperature range during work is between -10 °C and +40 °C.
- Manufacturing company reserves the right to change the technical properties without prior notice.

5. CONTROL PANELS

5.1. GKM 240 CONTROL PANEL



1. On/Off Switch (Açma Kapama Anahtarı)
2. Wire Speed Adjustment (Tel Hız Ayar Düğmesi)
3. Trigger Modes Selection (Tetik Modu Seçimi)
4. Torch Connection Euro (Torç Konnektörü Euro)
5. Time Selection for Trigger Modes (Tetik Mod Zaman Seçimi)
6. Voltage Steps Adj. Switch (Gerilim Ayar Şalteri)
7. Choke Coil Outputs (Şok Bobin Çıkışları (Şase Bağlantıları))

5.2. GKM 250 CONTROL PANEL




1. Trigger Modes Selection (Tetik Modu Seçimi)
2. Wire Speed Adjustment (Tel Hız Ayar Düğmesi)
3. Time Selection for Trigger Modes (Tetik Mod Zaman Seçimi)
4. On/Off Switch (Açma Kapama Anahtarı)
5. Voltage Steps Adj. Switch (Gerilim Ayar Şalteri)
6. Torch Connection Euro (Torç Konnektörü Euro)
7. Choke Coil Outputs (Şok Bobin Çıkışları, Şase Bağlantıları)

5.3. GKM 350-G, GKM 420-G, GKM 420-W CONTROL PANEL



1. Digital Display for Voltmeter (Voltmetre Dijital Ekranı)
2. Digital Display for Ampermeter (Ampermetre Dijital Ekranı)
3. Voltage Steps Adj. Switch (Gerilim Ayar Şalteri)
4. On/Off Switch (Açma Kapama Anahtarı)
5. Trigger Modes Selection (Tetik Modu Seçimi)
6. Wire Speed Adjustment (Tel Hız Ayar Düğmesi)
7. Time Selection for Trigger Modes (Tetik Mod Zaman Seçimi)
8. Torch Connection Euro (Torç Konnektörü Euro)
9. Choke Coil Outputs (Şok Bobin Çıkışları (Şase Bağlantıları))

5.4. GKM 350-2G, GKM 420-2G, GKM 420-2W CONTROL PANEL



1. Wire Speed Adjustment (Tel Hız Ayar Düğmesi)
2. Hot Water Input (Sıcak Su Girişi)
3. Torch Connection Euro (Torç Konnektörü Euro)
4. Cold Water Output (Soğuk Su Çıkışı)
5. Trigger Modes Selection (Tetik Modu Seçimi)
6. On/Off Switch (Açma Kapama Anahtarı)
7. Time Selection for Trigger Modes (Tetik Mod Zaman Seçimi)
8. Wire Feeding Motor Fuse 10A (Tel Sürme Motoru Sigortası 10A)
9. Fuse Error Indicator LED (Sigorta Uyarı Işığı)
10. Digital Display for Ampermeter / Voltmeter (Ampermetre / Voltmetre Dijital Ekranı)
11. Voltage Steps Adj. Switch (Gerilim Ayar Şalteri)
12. Choke Coil Outputs (Şok Bobin Çıkışları (Şase Bağlantıları))

5.5. GKM 500-2G, GKM 500-2W, GKM 600-2W CONTROL PANEL



1. Wire Speed Adjustment (Tel Hız Ayar Düğmesi)
2. Hot Water Input (Sıcak Su Girişi)
3. Cold Water Output (Soğuk Su Çıkışı)
4. Torch Connection Euro (Torç Konnektörü Euro)
5. On/Off Switch (Açma Kapama Anahtarı)
6. Wire Feeding Motor Fuse 10A (Tel Sürme Motoru Sigortası 10A)
7. Fuse Error Indicator LED (Sigorta Uyarı Işığı)
8. Trigger Modes Selection (Tetik Modu Seçimi)
9. Time Selection for Trigger Modes (Tetik Mod Zaman Seçimi)
10. Digital Display for Ampermeter / Voltmeter
(Ampermetre / Voltmetre Dijital Ekranı)
11. Voltage Steps Adj. Switch (Sensitive)
(Gerilim Ayar Şalteri – Hassas-)
12. Voltage Steps Adj. Switch (Rough)
(Gerilim Ayar Şalteri – Kaba-)
13. Choke Coil Outputs (Şok Bobin Çıkışları (Şase Bağlantıları))

6. LABEL INFORMATION

GeKaMac®		GEDİK KAYNAK SAN. VE TİC. A.Ş.	
www.gedikwelding.com		Ankara Cad. No:306 Şeyhli İstanbul/TURKEY	
GKM 240		S.N.: XXXXXXXX-24G-YYY	
MADE IN TURKEY		TS EN 60974-1/-10	
30 A / 21 V - 240 A / 30 V		X	
35%		60%	
100%		I ₂	
240 A		180 A	
140 A		U ₂	
26,5 V		23,0 V	
21,0 V		I ₁	
13,0 A		8,5 A	
6,0 A		S ₁	
8,0 kVA		4,8 kVA	
3,5 kVA		IP23	
U ₁ = 380 V		I _{max} = 13 A	
I ₁ Efektif = 10,5 A		3 ~	
50-60 Hz		0-23 m/min	
Cosφ= 0,95		TSE	
8691852009320		CE	

GeKaMac®		GEDİK KAYNAK SAN. VE TİC. A.Ş.	
www.gedikwelding.com		Ankara Cad. No:306 Şeyhli İstanbul/TURKEY	
GKM 250		S.N.: XXXXXXXX-25G-YYY	
MADE IN TURKEY		TS EN 60974-1/-10	
30 A / 21 V - 250 A / 30 V		X	
35%		60%	
100%		I ₂	
250 A		180 A	
140 A		U ₂	
26,5 V		23,0 V	
21,0 V		I ₁	
13,00 A		8,00 A	
5,75 A		S ₁	
8,1 kVA		4,8 kVA	
3,5 kVA		IP23	
U ₁ = 380 V		I _{max} = 13 A	
I ₁ Efektif = 9,2 A		3 ~	
50-60 Hz		0-22 m/min	
Cosφ= 0,95		TSE	
8691852009320		CE	

GeKaMac®		GEDİK KAYNAK SAN. VE TİC. A.Ş.	
www.gedikwelding.com		Ankara Cad. No:306 Şeyhli İstanbul/TURKEY	
GKM 350-G		S.N.: XXXXXXXX-35G-YYY	
MADE IN TURKEY		TS EN 60974-1/-10	
30 A / 15 V - 350 A / 32 V		X	
35%		60%	
100%		I ₂	
350 A		300 A	
180 A		U ₂	
30 V		27 V	
23 V		I ₁	
24,5 A		18,0 A	
13,6 A		S ₁	
15,6 kVA		10,5 kVA	
6,5 kVA		IP23	
U ₁ = 380 V		I _{max} = 24,5 A	
I ₁ Efektif = 17 A		3 ~	
50-60 Hz		0-22 m/min	
Cosφ= 0,95		TSE	
8691852009320		CE	

GeKaMac®		GEDİK KAYNAK SAN. VE TİC. A.Ş.	
www.gedikwelding.com		Ankara Cad. No:306 Şeyhli İstanbul/TURKEY	
GKM 350-2G		S.N.: XXXXXXXX-352G-YYY	
MADE IN TURKEY		TS EN 60974-1/-10	
30 A / 16 V - 350 A / 32 V		X	
35%		60%	
100%		I ₂	
350 A		270 A	
210 A		U ₂	
32,0 V		28,0 V	
17,5 V		I ₁	
25,0 A		19,5 A	
7,5 A		S ₁	
16,0 kVA		11,0 kVA	
6,5 kVA		IP23	
U ₁ = 380 V		I _{max} = 25 A	
I ₁ Efektif = 14,1 A		3 ~	
50-60 Hz		0-22 m/min	
Cosφ= 0,95		TSE	
8691852009320		CE	

GeKaMac®		GEDİK KAYNAK SAN. VE TİC. A.Ş.	
www.gedikwelding.com		Ankara Cad. No:306 Şeyhli İstanbul/TURKEY	
GKM 420-G		S.N.: XXXXXXXX-42G-YYY	
MADE IN TURKEY		TS EN 60974-1/-10	
30 A / 12 V - 420 A / 30 V		X	
35%		60%	
100%		I ₂	
420 A		320 A	
250 A		U ₂	
30 V		29 V	
20 V		I ₁	
30,0 A		25,0 A	
11,5 A		S ₁	
17,5 kVA		12,0 kVA	
7,1 kVA		IP23	
U ₁ = 380 V		I _{max} = 30 A	
I ₁ Efektif = 18,4 A		3 ~	
50-60 Hz		0-22 m/min	
Cosφ= 0,95		TSE	
8691852009320		CE	

GeKaMac®		GEDİK KAYNAK SAN. VE TİC. A.Ş.	
www.gedikwelding.com		Ankara Cad. No:306 Şeyhli İstanbul/TURKEY	
GKM 420-2G		S.N.: XXXXXXXX-422G-YYY	
MADE IN TURKEY		TS EN 60974-1/-10	
30 A / 12 V - 420 A / 30 V		X	
35%		60%	
100%		I ₂	
420 A		320 A	
250 A		U ₂	
30 V		29 V	
20 V		I ₁	
30,0 A		25,0 A	
11,5 A		S ₁	
17,5 kVA		12,0 kVA	
7,1 kVA		IP23	
U ₁ = 380 V		I _{max} = 30 A	
I ₁ Efektif = 18,4 A		3 ~	
50-60 Hz		0-22 m/min	
Cosφ= 0,95		TSE	
8691852009320		CE	

GeKaMac®		GEDİK KAYNAK SAN. VE TİC. A.Ş.	
www.gedikwelding.com		Ankara Cad. No:306 Şeyhli İstanbul/TURKEY	
GKM 420-W		S.N.: XXXXXXXX-42W-YYY	
MADE IN TURKEY		TS EN 60974-1/-10	
30 A / 12 V - 420 A / 30 V		X	
35%		60%	
100%		I ₂	
420 A		320 A	
250 A		U ₂	
30 V		29 V	
20 V		I ₁	
31,0 A		25,0 A	
11,5 A		S ₁	
17,6 kVA		12,1 kVA	
7,1 kVA		IP23	
U ₁ = 380 V		I _{max} = 31 A	
I ₁ Efektif = 18,4 A		3 ~	
50-60 Hz		0-22 m/min	
Cosφ= 0,95		TSE	
8691852009320		CE	

GeKaMac®		GEDİK KAYNAK SAN. VE TİC. A.Ş.	
www.gedikwelding.com		Ankara Cad. No:306 Şeyhli İstanbul/TURKEY	
GKM 420-2W		S.N.: XXXXXXXX-422W-YYY	
MADE IN TURKEY		TS EN 60974-1/-10	
30 A / 12 V - 420 A / 30 V		X	
35%		60%	
100%		I ₂	
420 A		320 A	
250 A		U ₂	
30 V		29 V	
20 V		I ₁	
30,5 A		25,0 A	
11,5 A		S ₁	
17,6 kVA		12,1 kVA	
7,1 kVA		IP23	
U ₁ = 380 V		I _{max} = 30,5 A	
I ₁ Efektif = 18,4 A		3 ~	
50-60 Hz		0-22 m/min	
Cosφ= 0,95		TSE	
8691852009320		CE	

GeKaMac		GEDİK KAYNAK SAN. VE TİC. A.Ş.			
www.gedikwelding.com		Ankara Cad. No:306 Şeyhli İstanbul/TURKEY			
GKM 500-2G		S.N.: XXXXXXXX-502G-YYY			
		TS EN 60974-1/-10			
		40 A / 17 V - 500 A / 38 V			
		X	X%	60%	100%
$U_0 = 16-57 \text{ V}$		I_2	500 A	380 A	
$U_1 = 380 \text{ V}$		U_2	38,0 V	26,5 V	
I_1		I_1	42,5 A	18,9 A	
S_1		S_1	27,5 kVA	14,5 kVA	
IP23		$I_{\max} = 42,5 \text{ A}$	$I_1 \text{ Efektif} = 30 \text{ A}$		
			0-22 m/min	$\cos\phi = 0,95$	

GeKaMac		GEDİK KAYNAK SAN. VE TİC. A.Ş.			
www.gedikwelding.com		Ankara Cad. No:306 Şeyhli İstanbul/TURKEY			
GKM 500-2W		S.N.: XXXXXXXX-502W-YYY			
		TS EN 60974-1/-10			
		40 A / 16,2 V - 500 A / 41 V			
		X	X%	60%	100%
$U_0 = 16-52 \text{ V}$		I_2	500 A	380 A	
$U_1 = 380 \text{ V}$		U_2	41,0 V	27,5 V	
I_1		I_1	43,0 A	18,9 A	
S_1		S_1	27,6 kVA	14,6 kVA	
IP23		$I_{\max} = 43 \text{ A}$	$I_1 \text{ Efektif} = 30 \text{ A}$		
			0-22 m/min	$\cos\phi = 0,95$	

GeKaMac		GEDİK KAYNAK SAN. VE TİC. A.Ş.			
www.gedikwelding.com		Ankara Cad. No:306 Şeyhli İstanbul/TURKEY			
GKM 600-2W		S.N.: XXXXXXXX-602W-YYY			
		TS EN 60974-1/-10			
		30 A / 15 V - 600 A / 44 V			
		X	35%	60%	100%
$U_0 = 18-60 \text{ V}$		I_2	600 A	520 A	400 A
$U_1 = 380 \text{ V}$		U_2	44,0 V	34,0 V	29,5 V
I_1		I_1	60 A	50 A	33 A
S_1		S_1	33,6 kVA	28,5 kVA	18,5 kVA
IP23		$I_{\max} = 60 \text{ A}$	$I_1 \text{ Efektif} = 35 \text{ A}$		
			0-22 m/min	$\cos\phi = 0,90$	



Class 2




Wire Feed Wire



Direct Current



Three-Phase Transformer Rectifier



Network Input Three-Phase Alternative Current



Suitable for welding in an environment with increased hazard of electric shock



MIG/MAG Welding

X = Duty Cycle

U_0 = No-Load Voltage

U_1 = Supply Voltage

U_2 = Welding Voltage

I_1 = Input Voltage

I_2 = Welding Voltage

IP21 = Protection Class

S_1 = Input Power

7. TECHNICAL INFORMATION

	Unit	GKM 240	GKM 250	GKM 350-G	GKM 350-2G	GKM 420-G
Main Voltage	V	380	380	380	380	380
Maximum Power	kVA	8,0	8,1	15,6	16,0	17,5
Adjustment Range	A	30 - 240	30 - 250	30 - 350	30 - 350	30 - 420
Power Factor		0,95	0,95	0,95	0,95	0,95
Welding Range (%35)		240	250	350	350	420
Welding Range (%60)		180	180	270	270	320
Welding Range (%100)		140	140	210	210	250
Open Circuit Voltage	V	13 - 32	13 - 32	13 - 35	13 - 35	13 - 43
Isolation Class		H	H	H	H	H
Protection Class		IP 23	IP 23	IP 23	IP 23	IP 23
Standart		EN 60974-1/10 EN 60529	EN 60974-1/10 EN 60529	EN 60974-1/10 EN 60529	EN 60974-1/10 EN 60529	EN 60974-1/10 EN 60529
Dimension	mm (V*W*H)	800/420/670	930/480/900	930/480/900	1075/500/800	1075/500/800
Weight	kg	82	75	125	140	140
Wire Diameter	mm	0,8-1,0	0,8-1,0	0,8-1,0-1,2	0,8-1,0-1,2	0,8-1,0-1,2

	Unit	GKM 420-2G	GKM 420-W	GKM 420-2W
Main Voltage	V	380	380	380
Maximum Power	kVA	17,5	17,6	17,6
Adjustment Range	A	30 - 420	30 - 420	30 - 420
Power Factor		0,95	0,95	0,95
Welding Range (%35)		420	420	420
Welding Range (%60)		320	320	320
Welding Range (%100)		250	250	250
Open Circuit Voltage	V	13-43	13-43	13-43
Isolation Class		H	H	H
Protection Class		IP23	IP23	IP23
Standard		EN 60974-1/10 EN 60529	EN 60974-1/10 EN 60529	EN 60974-1/10 EN 60529
Dimension	mm	1075/500/800	1075/500/800	1075/500/800
Weight	kg	155	165	177
Wire Diameter	mm	0,8-1,0-1,2	0,8-1,0-1,2	0,8-1,0-1,2

	Unit	GKM 500-2W	GKM 500-2G	GKM 600-2W
Main Voltage	V	380	380	380
Maximum Power	kVA	27,6	27,5	33,6
Adjustment Range	A	40 - 500	40 - 500	40 - 600
Power Factor		0,95	0,95	0,90
Welding Range (%35)		X	X	600
Welding Range (%60)		500	500	520
Welding Range (%100)		380	380	400
Open Circuit Voltage	V	16 - 57	16 - 57	18 - 60
Isolation Class		H	H	H
Protection Class		IP23	IP23	IP23
Standard		EN 60974-1/10 EN 60529	EN 60974-1/10 EN 60529	EN 60974-1/10 EN 60529
Dimension	mm	1100/510/1440	1100/510/1440	1100/510/1440
Weight	kg	245	226	280
Wire Diameter	mm	0,8-1,0-1,2 -1,6	0,8-1,0-1,2 -1,6	0,8-1,0-1,2 -1,6

8. MACHINE SET UP INFORMATION

- Read this section carefully before setting up or operating the machine.
- Do not place the machine on a plane that is at more than 15 degrees with the horizontal and do not operate it on such a plane.
- The machine must be operated in an environment where there is a flow of clean air and there must be no factor that inhibits the ventilation or that stops the flow of air. The machine should not be covered with paper, dustcloth or similar objects while working.
- Dust and dirt can enter into the machine. This situation should be minimized as much as possible. Don't work in environments that are extremely dusty and that have water, paint and oil granules and grinding dusts and corrosive gases in their atmosphere.
- This machine has IP 23 class protection. Keep the machine as dry as possible and don't place it on surfaces that are wet or have puddles on them.
- Definitely do not operate the machine under sunlight and at places where there is a possibility of splashing of water.
- Place the machine far from appliances that are radio controlled. The normal operation of the machine can affect the operation of this type of appliances that are nearby in a negative way and in this situation, can cause injury and equipment malfunction. Read the "Electromagnetic Compatibility" section in this user's guide.
- Do not operate the machine at places where the environmental temperature is either below -10°C or above +40°C and humidity is above 70%.
- The opening of the chassis cover and the interventions made by unauthorized people concerning electrical equipment can create life threatening situations. The people who act in a contrary way, are considered to have accepted in advance the negative results that can come up.
- The operational efficiency of the machine, is the percentage of time that the welder can weld for 10 minutes at a given welding current without excessive heating and without taking a break.
- The machine is protected against excessive heating by the help of thermal protection. When this protection comes on-line, the warning light on the front panel will come on. When the safe operating temperature is reached again, the light will turn off and welding will continue.

9. MACHINE MAINTENANCE

- The maintenance and service must be done only by qualified personel! The network current of the welding machine should be cut off during maintenance and service. Electric plug of the machine must be removed from the jack.
- Obey the general personal safety and fire safety rules that deal with welding operations.
- Control the insulation state and connections of cable conductors and energy cable.
- Remove the connections that have become loose.
- The dust which has accumulated inside the welding machine should be cleaned with compressed air regularly. If the machine is being used in an environment that contains a lot of dust and fume, this operation should be repeated twice a month.
- Need to be careful about the pressure of the air that is being used for cleaning in order to protect small pieces.

- The entry of water and steam into the welding machine should be inhibited. If the machine is affected by the humidity, the inside of the machine should be dried and insulation should be controlled.
- If the welding machine is not going to be used for a long time, it should be stored at a dry place.
- The welding machine should not be thrown at random and must be protected from hits while being put away or transported

10. STORAGE AND TRANSPORTATION

- The welding machine should be stored in closed rooms that have environmental temperatures between -10°C and +40°C with a humidity of at the most 70%.
- Incendiary, conductive dust or other environmental elements should not be found in the room.
- It is recommended that the welding machines should be preserved in a proper way.
- The welding machine should be packaged in a way that will protect it from mechanical damages during long distance transportation.

11. GAS METAL ARC WELDING METHOD

The operations that are listed below should be performed before starting to weld:

- Points to consider in the gas metal arc welding method

a- Gas Tube

Place the gas tube in the open area behind the welding machine and tighten the tube in such a way that it won't fall with the help of the chain above. Affix the gas regulator to the tube. Affix the hose that is located at the rear outlet of the welding machine to the outlet of the gas regulator and squeeze it. Loosen the screw below the gas regulator by turning it to the left (you will have closed off the gas inlet of the machine this way).

b- Torch Connection

Place the torch cable at its place in the wire feed unit carefully and tighten it into its place with the use of clamp screw.

c- Gas Metal Arc Welding Wire

Take the roller out of its package. Turn the roller around until you are certain that the roller will turn counterclockwise once it is placed inside the machine. Then, place the roller into the socket which is located inside the machine. Pushing the roller and the projection on the socket forward will make the task of affixing easier.

d- Wire Feed System

Let us open the pressure levers that are found on the wire feed system. At this point, let us push the wire, which is rolled up on a roller, past the wire feed point which is located inside torch connection (central connection) after passing it through the wire guides located in the wire feed system. The closing of the pressure levers again, places the wire into the wire feed system. Provide for the advancement of the wire through and 20mm past the torch by turning on the machine.

- Adjust the proper welding current value, which you will determine according to the diameter and type of the electrode, welding position and wire information log, by the use of amper adjustment lever which is located at the top of the machine.
- Start welding by obeying the rules of welding.


12. GAS METAL ARC WELDING MACHINE PROBLEMS

FAULT	PROBABLE REASON	SOLUTION
The machine is not welding.	There can be a problem with the supply cable or supply voltage of the machine.	Check it.
	The machine could have been deactivated by the thermostat due to excessive heat.	Check it.
	The pump circuit breaker may be in the (0) position or may be faulty.	Check it.
	The power line inside the torch may be broken.	Check it, if it is necessary, get any one.
	There may be a problem with the power line of the connecting cable.	Check it, if it is necessary, get any one.
	The electronic card of the machine may be faulty.	Call the technical service
	The contactor may be faulty.	Call the technical service
The machine is welding at low current.	One less phase may be coming to the machine.	Check it.
	The rectifier group can be faulty.	Call the technical service
	The package type switch of the machine may be faulty.	Check it and get any one.
	The coils of the machine may be faulty.	Call the technical service
	There can be a looseness of contact in the internal cable connections of the machine.	Check it.
	The switches of the contactor may not be conducting a phase.	Check it.
If insufficient gas is coming from the end of the torch or if there is no gas coming out?	The gas valve may be faulty.	Check it, if it is necessary, get any one.
	The flow meter may be faulty.	Check it, if it is necessary, get any one.
	The gas hose inside the torch may have been damaged.	Change the gas hose.
	The torch adaptor gas canal may be clogged up.	Clean the gas canal.

FAULT	PROBABLE REASON	SOLUTION
	The tube may be completely empty.	Change the tube.
The wire feed motor doesn't work.	Its fuse may have blown.	Check it.
	Motor cables inside the connecting cable may be broken.	Check it, if it is necessary, get any one.
	The electronic card of the machine may be faulty.	Call the technical service
	There may be a problem with the card transformer.	Call the technical service.
	The potentiometer may be faulty (22K).	Check it and change it.
	Thyristor module may be faulty.	Call the technical service
	Welding method selection switch may be faulty or a cable of it may be broken.	Check it, if it is necessary, get any one.
	Wire feed motor may be faulty.	Call the technical service
There is an electrical leakage in the machine.	No neutral/ground line is coming to the casing of the machine.	Check it.
Wire inflection is taking place at the outlet of the wire feed roller.	The guide tube has moved very far away from the wire feed roller.	Check it and correct.
	Pressure spring may be firmer than necessary.	Loosen little bit pressure spring.
	The inside of the spiral may be clogged up with dusts of iron. Every wire should be cleaned with dry air at the end.	Clean the inside of the spiral.
	The spiral may be bent.	Correct the spiral.
	Burr might be stuck to the inside of current nozzle which can make it more difficult for the wire to get through.	Check it.
There is a water leakage in the machine's water cooling system.	Water couplers may be faulty.	Check it, if it is necessary, get any one.
	Water hoses might have bursted.	Check it, if it is necessary, get any one.


13. SPARE PARTS

13.1. Spare Parts of GeKaMac® GKM 240




PICTURES NUMBERS		PRODUCT CODE	MATERIAL DESCRIPTION
1		201094	GKM 240 COMPLETE LID WITH A HANDLE
2	a	105662	RIGHT HAND HANDLE
	b	201102	GKM 240 PAINTED HANDLE PROFILE
	c	105661	LEFT HAND HANDLE
3	a	105557	WIRE FEED MOTOR
	b	105699	ROLLER
	c	201714	WIRE FEED CARRIER
4		101521	BRAKE CYLINDER
5		100858	FLANGE
6		105728	GKM 240 PACKAGE TYPE SWITCH
7		206001	FEMALE JACK SET 50 / 70
8		201062	GKM 240 COMPLETELY PAINTED CASING
9		101472	GKM 240 MOBILE WHEEL
10		101471	GKM 240 FIXED WHEEL
11		101303	220 V UNDERPLASTER GROUNDING PLUG
12		101446	13,5 mm. PLASTIC UNION STEM
13		201077	TUBE HOLDER
14		201046	GKM 240 COMPLETE CHOKE COIL
15		101461	GKM 240 FAN MOTOR
16		100507	GKM 240 RECTIFIER GROUP
17		201011	GKM 240 COMPLETE TRANSFORMER (WITH CIRCUIT BREAKER)
18		101391	GKM 240 TRANSFORMER CARD
19		101363	GKM 240 CONTACTOR (LC1D1818D5)
20		106408	42 VOLT VALVE
21		105698	THYRISTOR MODULE
22		201030	X2 CABLING GROUP (FOR GKM 240)
23		101360	MR.12 ELECTRONIC CARD
24		101295	NR:3 SHORT CIRCUIT ELECTRIC TERMINAL
25		101446	13,5 mm PLASTIC UNION STEM
26		201090	GKM 240 COMPLETE SCREW CAP

13.2. Spare Parts of GeKaMac® GKM 250



PICTURES NUMBERS		PRODUCT CODE	MATERIAL DESCRIPTION
1		202547	GKM 250 SCREW CAP
2		101390	GKM 250 CARD TRANSFORMER
3		105698	THYRISTOR MODULE
4		101360	MR12 ELECTRONIC CARD
5		101391	GKM 240 TRANSFORMER CARD
6		101363	GKM 250 CONTACTOR (LC1D1818D5)
7		105728	GKM 250 PACKAGE TYPE SWITCH
8		201030	X2 CABLING GROUP (FOR GKM 250)
9		100858	FLANGE
10		206001	FEMALE JACK SET 50 / 70
11	a	105662	RIGHT HAND HANDLE
	b	201102	GKM 240 PAINTED HANDLE PROFILE
	c	105661	LEFT HAND HANDLE
12		106079	GKM 250 MOBILE WHEEL
13		106080	GKM 250 FIXED WHEEL
14		106082	GKM 250 GLASS FUSE HOUSING
15		106408	42 VOLT VALVE
16		101446	13,5 mm PLASTIC UNION STEM
17		106067	WIRE FEED MOTOR
18		101521	BRAKE CYLINDER
19		201930	GKM 250 CHOKE COIL
20		201928	GKM 250 COMPLETE TRANSFORMER
21		100507	GKM 250 RECTIFIER GROUP
22		106077	GKM 250 FAN
23		202549	GKM 250 HINGED LID


13.3. Spare Parts of GeKaMac® GKM 350-G, GKM 350-2G



PICTURES NUMBERS		PRODUCT CODE	MATERIAL DESCRIPTION
1		201280	GKM 350/420 SIDE LID
2		101304	0-1 SWITCH
3		206001	50-70 FEMALE CONNECTION ELEMENT
4		201193	GKM 350/420 METAL BODY
5		101470	GKM 350/420 MOBILE WHEEL
6		101469	GKM 350/420 FIXED WHEEL
7		201178	GKM 350 CHOKE COIL
8		202545	GKM 350 TRANSFORMER
9		100505	GKM 350 RECTIFIER GROUP
10		101380	300A SHUNT
11		101364	GKM 350 CONTACTOR
12		105698	THYRISTOR MODULE
13		101389	CARD TRANSFORMER
14		101462	FAN (25CM)
15		203280	GKM 350 FAN PROTECTION SHEET METAL
16		201288	GKM 350 TOP LID
17		105726	12-STAGE PACKAGE TYPE SWITCH
18	a	201344	TIME ADJUSTMENT SWITCH
	b	105656	25K POTENTIOMETER
19	a	201140	WELDING METHOD SELECTION SWITCH
	b	105665	2X6 COMMUTATOR SWITCH
20		107534	GKM A/V ELECTRONIC CARD
22		101297	ELECTRIC TERMINAL
23		201446	X2 CABLE GROUP
24		201173	X1 CABLE GROUP
25		101360	MR 12 ELECTRONIC CARD
26	a	101537	PLASTIC HANDLE (LEFT)

PICTURES NUMBERS		PRODUCT CODE	MATERIAL DESCRIPTION
	b	201299	PROFILE LEVER
	c	101538	PLASTIC HANDLE (RIGHT)
27		105758	WIRE FEED UNIT STUD
28		106116	WIRE FEED UNIT MOBILE WHEEL
29		106117	WIRE FEED UNIT FIXED WHEEL
30		106408	GAS VALVE
31		206103	CONNECTING CABLE CLAMP
32		101297	ELECTRIC TERMINAL
33		101446	13,5 mm UNION STEM
34		201233	WIRE FEED UNIT METAL BODY
35		100858	FLANGE
36		105748	6MM WATER COUPLING
37	a	201003	WIRE SPEED ADJUSTMENT SWITCH
	b	105656	25K POTENTIOMETER
38		202523	BRAKE CYLINDER
39	a	105557	WIRE FEED MOTOR
	b	106032	WIRE FEED SYSTEM
	c	106039	WIRE FEED ROLLER(0,8 mm-1,0 mm)
	d	100857	WIRE FEED CENTRAL CONNECTION ADAPTOR
40		201268	WIRE FEED LID (WITH HANDLE)
41		106096	PLASTIC SLIDING LID LOCK
42		101037	WIRE FEED CARRIER PLASTIC HANDLE
43		201264	WIRE FEED UNIT LID (WITH SCREW)
44		105731	FEMALE SOCKET
45		106247	220V PLUG
46		101448	29 UNION STEM
47		204064	TUBE HOLDER


13.4. Spare Part List of GeKaMac® GKM 420-W, GKM 420-G, GKM 420-2W, GKM 420- 2G



PICTURES NUMBERS		PRODUCT CODE	MATERIAL DESCRIPTION
1		201280	GKM 350/420 SIDE LID
2		101304	0-1 SWITCH
3		206001	50-70 FEMALE CONNECTION ELEMENT
4		201193	GKM 350/420 METAL CASING
5		101470	GKM 350/420 MOBILE WHEEL
6		101469	GKM 350/420 FIXED WHEEL
7		201468	GKM 420 CHOKE COIL
8		201413	GKM 420 TRANSFORMER
9		100510	GKM 420 RECTIFIER GROUP
10		101381	400A SHUNT
11		101365	GKM 420 CONTACTOR
12		105698	THYRISTOR MODULE
13		101389	AUXILIARY TRANSFORMER
14		101462	FAN (25CM)
15		203290	GKM 350/420 FAN PROTECTION SHEET METAL
16		201288	GKM 350/420 TOP LID
17		105835	18 STAGE PACKAGE TYPE SWITCH
18	a	201344	TIME ADJUSTMENT SWITCH
	b	105656	25K POTENTIOMETER
19	a	201140	WELDING METHOD SELECTION SWITCH
	b	105665	2X6 COMMUTATOR SWITCH
20		107534	GKM A/V ELECTRONIC CARD
22		101297	ELECTRIC TERMINAL
23		201446	X2 CABLE GROUP

PICTURES NUMBERS		PRODUCT CODE	MATERIAL DESCRIPTION
24		201455	X1 CABLE GROUP
25		101360	MR 12 ELECTRONIC CARD
26	a	101537	PLASTIC HANDLE (LEFT)
	b	201299	PROFILE LEVER
	c	101538	PLASTIC HANDLE (RIGHT)
27		105758	WIRE FEED UNIT STUD
28		106116	WIRE FEED UNIT MOBILE WHEEL
29		106117	WIRE FEED UNIT FIXED WHEEL
30		106408	GAS VALVE
31		206103	CONNECTING CABLE CLAMP
32		101297	ELECTRIC TERMINAL
33		101446	13,5 mm UNION STEM
34		201233	WIRE FEED UNIT METAL CASING
35		100858	FLANGE
36		105748	6mm WATER COUPLING
37	a	201003	WIRE SPEED ADJUSTMENT SWITCH
	b	105656	25K POTENTIOMETER
38		202523	BRAKE CYLINDER
39	a	105557	WIRE FEED MOTOR
	b	106009	WIRE FEED SYSTEM (1,0 mm-1,2 mm)
	c	106040	WIRE FEED ROLLER (1,0 mm-1,2 mm)
	d	100857	WIRE FEED CENTRAL CONNECTION ADAPTOR
40		201268	WIRE FEED LID (WITH HANDLE)
41		106096	PLASTIC SLIDING LID LOCK
42		101037	WIRE FEED CARRYING PLASTIC HANDLE
43		201264	WIRE FEED UNIT LID (WITH SCREW)
44		105731	FEMALE SOCKET
45		106247	220V PLUG
46		101448	29 UNION STEM
47		201499	PUMP UNIT
48		101476	WATER TANK
49		101477	WATER TANK LID
50		105749	MOTOR PROTECTION CIRCUIT BREAKER
51		202485	RADIATOR
52		206152	PROPELLER
53		105894	PUMP MOTOR
54		201445	CONNECTING CABLE (5 m)
55		204064	TUBE HOLDER


13.5. Spare Parts of GeKaMac® GKM 500-2W, GKM 500-2G



PICTURES NUMBERS		PRODUCT CODE	MATERIAL DESCRIPTION
1		201760	GKM 500/600 SIDE LID
2	a	201140	WELDING METHOD SELECTION SWITCH
	b	105665	2X6 COMMUTATOR SWITCH
3	a	201344	TIME ADJUSTMENT SWITCH
	b	105656	25K POTENTIOMETER
4		107534	GKM A/V ELECTRONIC CARD
6		101304	0-1 SWITCH
7		101369	1-9 PACKAGE TYPE SWITCH
8		101370	1-4 PACKAGE TYPE SWITCH
9		101438	70-95 FEMALE CONNECTION ELEMENT
10		201733	GKM 500/600 METAL CASING
11		101473	GKM 500/600 MOBILE WHEEL
12		101474	GKM 500/600 FIXED WHEEL
13		201712	GKM 500/600 CHOKE COIL
14		202467	GKM 500 TRANSFORMER
15		100503	GKM 500 RECTIFIER
16		101382	600 A SHUNT
17		101371	GKM 500/600 CONTACTOR
18		101388	PUMP TRANSFORMER
19		101389	ELECTRONIC CARD TRANSFORMER
20		101464	30 cm FAN
21		201744	GKM 500 FAN SHEET METAL
22		201764	GKM 500 TOP LID
23		105698	THYRISTOR MODULE

PICTURES NUMBERS		PRODUCT CODE	MATERIAL DESCRIPTION
24		201692	GKM 500 X1 CABLE GROUP
25		201702	GKM 500 X2 CABLE GROUP
26		101360	MR12 ELECTRONIC CARD
27		106116	WIRE FEED UNIT MOBILE WHEEL
28	a	101537	PLASTIC RIGHT HAND HANDLE
	b	201775	PROFILE LEVER
	c	101538	PLASTIC LEFT HAND HANDLE
29		106408	GAS VALVE
30		206103	CONNECTING CABLE CLAMP
31		101297	NR:2 TERMINAL STRIPS
32		101446	13,5 UNION STEM
33		106117	WIRE FEED UNIT FIXED WHEEL
34		100858	FLANGE
35		105748	6mm WATER COUPLING
36	a	201003	WIRE SPEED ADJUSTMENT SWITCH
	b	105656	25K POTENTIOMETER
37		202523	BRAKE CYLINDER (SET)
38	a	105557	WIRE FEED MOTOR
	b	106009	WIRE FEED SYSTEM(1,0 mm-1,2 mm)
	c	106040	WIRE FEED ROLLER(1,0 mm-1,2 mm)
	d	100857	CENTRAL CONNECTION ADAPTOR
39		201268	WIRE FEED SYSTEM LID (LEFT)
40		106096	PLASTIC LID LOCK
41		101037	PLASTIC HANDLE
42		201233	WIRE FEED UNIT METAL CASING
43		201264	WIRE FEED SYSTEM LID (RIGHT)
44		105731	FEMALE SOCKET
45		106082	GLASS FUSE HOUSING
46		106247	220V PLUG
47		101448	29 UNION STEM
48		201499	PUMP UNIT
49		101476	WATER TANK
50		101477	WATER TANK LID
51		105749	MOTOR PROTECTION CIRCUIT BREAKER
52		202485	RADIATOR
53		206152	PROPELLER
54		105894	PUMP MOTOR
55		201994	CONNECTING CABLE (5 m)
56		105758	WIRE FEED UNIT STUD
57		204064	TUBE HOLDER

13.6. Spare Parts of GeKaMac® GKM 600-2W



PICTURES NUMBERS		PRODUCT CODE	MATERIAL DESCRIPTION
1		201760	GKM 500/600 SIDE LID
2	a	201140	WELDING METHOD SELECTION SWITCH
	b	105665	2X6 COMMUTATOR SWITCH
3	a	201344	TIME ADJUSTMENT SWITCH
	b	105656	25K POTENTIOMETER
4		107534	GKM A/V ELECTRONIC CARD
6		101304	0-1 SWITCH
7		101369	1-9 PACKAGE TYPE SWITCH
8		101370	1-4 PACKAGE TYPE SWITCH
9		101438	70-95 FEMALE CONNECTION ELEMENT
10		201733	GKM 500/600 METAL CASING
11		101473	GKM 500/600 MOBILE WHEEL
12		101474	GKM 500/600 FIXED WHEEL
13		201712	GKM 500/600 CHOKE COIL
14		202661	GKM 600 TRANSFORMER
15		100504	GKM 600 RECTIFIER
16		101382	600 A SHUNT
17		101371	GKM 500/600 CONTACTOR
18		101388	PUMP TRANSFORMER
19		101389	ELECTRONIC CARD TRANSFORMER
20		101464	30 cm FAN
21		201744	GKM 500 FAN SHEET METAL
22		201764	GKM 500 TOP LID
23		105698	THYRISTOR MODULE
24		201692	GKM 500 X1 CABLE GROUP
25		201702	GKM 500 X2 CABLE GROUP
26		101360	MR12 ELECTRONIC CARD

PICTURES NUMBERS		PRODUCT CODE	MATERIAL DESCRIPTION
27		106116	WIRE FEED UNIT MOBILE WHEEL
28	a	101537	PLASTIC RIGHT HAND HANDLE
	b	201775	PROFILE LEVER
	c	101538	PLASTIC LEFT HAND HANDLE
29		106408	GAS VALVE
30		206103	CONNECTING CABLE CLAMP
31		101297	NR:2 TERMINAL STRIPS
32		101446	13,5 UNION STEM
33		106117	WIRE FEED UNIT FIXED WHEEL
34		100858	FLANGE
35		105748	6 mm WATER COUPLING
36	a	201003	WIRE SPEED ADJUSTMENT SWITCH
	b	105656	25K POTENTIOMETER
37		202523	BRAKE CYLINDER(SET)
38	a	105557	WIRE FEED MOTOR
	b	106009	WIRE FEED SYSTEM(1,0 mm-1,2 mm)
	c	106040	WIRE FEED ROLLER(1,0 mm-1,2 mm)
	d	100857	CENTRAL CONNECTION ADAPTOR
39		201268	WIRE FEED SYSTEM LID (LEFT)
40		106096	PLASTIC LID LOCK
41		101037	PLASTIC HANDLE
42		201233	WIRE FEED UNIT METAL CASING
43		201264	WIRE FEED SYSTEM LID (RIGHT)
44		105731	FEMALE SOCKET
45		106082	GLASS FUSE HOUSING
46		106247	220V PLUG
47		101448	29 UNION STEM
48		201499	PUMP UNIT
49		101476	WATER TANK
50		101477	WATER TANK LID
51		105749	MOTOR PROTECTION CIRCUIT BREAKER
52		202485	RADIATOR
53		206152	PROPELLER
54		105894	PUMP MOTOR
55		201748	CONNECTING CABLE
56		105758	WIRE FEED UNIT STUD
57		204064	TUBE HOLDER

14. WARRANTY CONDITIONS

1. The length of the warranty starts on the date of delivery and it is for 1 year.
2. The whole merchandise including all its parts are covered by the warranty of our company.
3. If the merchandise breaks down within the length of the warranty, the time spent in the repair shop will be added to the length of the warranty. The length of repair of the merchandise is at the maximum 20 working days. This period of time starts on the date that the merchandise was delivered at one of the following locations: A service station or the seller of the merchandise or dealer or agency or representation office or importer or manufacturer, in this order if there are no service stations.
4. If the merchandise breaks down either due to material and workmanship or assembly lines within the length of the Warranty, it will be repaired without demanding any money under the name of expenditure of workmanship, the cost of the changed piece or under any other name.
5. Replacement operation will be done without charge in cases where the merchandise repeats the same fault more than twice or different faults come up more than four times within the length of the warranty, the length of the repair exceeds maximum necessary time and the determination of the unrepairability of the merchandise by a report that is prepared either by a service station or the seller or a dealer or an agency or a representation office or the importer or the manufacturer, in this order, if there are no service stations.
6. Faults that are results of misuse according to the user's guide of the merchandise are not covered by the warranty.
7. Ministry of Science Industry and Technology, The Protection of the Consumer and Competition General Directorate can be referred to whenever a problem concerning the warranty document comes up.
8. Earth clamp and electrode holder kits are not under warranty.

GeKaMac®

Gedik Welding Machines

Warranty Document

MACHINE INFORMATION

Brand : GeKaMac®

Model :

Serial Number :

CUSTOMER INFORMATION

Company Name :

Authorized Person :

Telephone :

Company Address :

City/Country.....

E-Mail :..... @.....

Signature /Cachet :

SERVICE INFORMATION

Authorized Service :

Service Staff :

Installation Date :/...../.....

Warranty Starting Date :

Warranty Expiration Date :

Signature /Cachet

GeKaMac®

Gedik Welding Machines

Warranty Document

MACHINE INFORMATION

Brand : GeKaMac®

Model :

Serial Number :

CUSTOMER INFORMATION

Company Name :

Authorized Person :

Telephone :

Company Address :

City/Country.....

E-Mail :..... @.....

Signature /Cachet :

SERVICE INFORMATION

Authorized Service :

Service Staff :

Installation Date :/...../.....

Warranty Starting Date :

Warranty Expiration Date :

Signature /Cachet

GKMac Series



GeKaMac®



Gedik Welding — Ankara Caddesi
No : 306 Şeyhli 34906 Pendik, İstanbul / Turkey
T +90 216 378 50 00 F +90 216 378 20 44
gedik@gedik.com.tr