



GeKaMac®



Power TIG 3201 AC/DC Pulse Users Manual

Please Read and Understand This Manual
Before Operating The Welding Machine

www.gedikwelding.com

Dear Customer

Thank you for choosing our product! This instruction manual will help you get to know your new machine. Read the manual carefully and you will soon be familiar with all the many great features of your new product. Please also take special note of the safety rules in the manual and follow exactly the instructions.

If you treat your product carefully, this definitely helps to prolong its enduring quality and reliability. For more information, please contact us or consult authorized distributor.

The products in the manual may be changed without prior notice. The model you purchase is for:

- PoWer TIG 3201 AC/DC Pulse

Please find corresponding models from the "Contents".

Important:

Please read carefully the safety rules given in the manual and follow exactly the instructions to avoid potential hazard and injury.

Safety Rules



“**Danger**” indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



“**Warning!**” indicates a possible hazardous situation which, if not avoided, could result in death or serious injury. The possible hazards are explained in the text.



“**Caution**” indicates a possible hazardous situation which, if not avoided, may result in slight or moderate injury.



“**Note!**” indicates a situation which implies a risk of impaired welding result and damage to the equipment.

“**Important!**” indicates practical tips and other useful special-message. It is no signal word for a harmful or dangerous situation.



Utilisation for intended purpose only

- The machine may only be used for jobs as defined by the “Intended purpose”.
- Utilisation for any other purpose, or in any other manner, shall be deemed to be “not in accordance with the intended purpose”. The manufacturer shall not be liable for any damage resulting from such improper use.



Safety signs

- All the safety instructions and danger warnings on the machine must be kept in legible condition, not removed, not be covered, pasted or painted cover.



Safety inspection

- The owner/operator is obliged to perform safety inspection at regular intervals.
- The manufacturer also recommends every 3-6 months for regular maintenance of power sources.



Electric shock can kill

- Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In MIG/MAG welding, the wire, drive rollers, wire feed housing and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.
- Do not touch live electrical parts of the welding circuit, electrodes and wires with your bare skin or wet clothing.
- The operator must wear dry hole-free insulating welding gloves and body protection while performs the welding.
- Insulate yourself from work and ground using dry insulating protection which is large enough to prevent you full area of physical contact with the work or ground.
- Connect the primary input cable according to rules. Disconnect input power or stop machine before installing or maintenance.
- If welding must be performed under electrically hazardous conditions as follow: in damp locations or wearing wet clothing; on metal structures such as floors, gratings, or scaffolds; when in cramped positions such as sitting, kneeling, or lying; or in occasion when there is a high risk of unavoidable or accidental contact with the work piece or ground. Must use additional safety precautions: semiautomatic DC constant voltage (wire) welder, DC manual (Stick) welder and AC welder with reduced open-load voltage.
- Maintain the electrode holder, ground clamp, welding cable and welding machine in good, safe operating condition. Replace damaged part immediately.

Electric and magnetic fields (EMF) may be dangerous

- If electromagnetic interference is found to be occurring, the operator is obliged to examine any possible electromagnetic problems that may occur on equipment as follow:

- minas, signal and data-transmission leads
- IT and telecoms equipment
- measurement and calibration devices
- Wearers of pacemakers

- Measures for minimizing or preventing EMC problems:

- Mains supply

If electromagnetic interference still occurs, despite the fact that the mains connection in accordance with the regulations, take additional measures

- Welding cables

Keep these as short as possible

Connect the work cable to the work piece as close as possible to the area being welded.

Lay tem well away from other cables.

Do not place your body between your electrode and work cables.

- Equipotential bonding
- Workpiece grounding (earthing)



- Shielding

Shield the entire welding equipment and other equipment nearby.



ARC rays can burn

- Visible and invisible rays can burn eyes and skin.
- Wear an approved welding helmet or suitable clothing made from durable flame-resistant material (leather, heavy cotton, or wool) to protect your eyes and skin from arc rays and sparks when welding or watching.
- Use protective screens or barriers to protect other nearby personnel with suitable, non-flammable screening and/or warn them not to watch the arc nor expose themselves to the arc rays or to hot spatter or material.



Fumes and gases can be dangerous

- Welding may produce fumes and gases, breathing these fumes and gases can be hazardous to your health.
- When welding, keep your head out of the fume. If inside, ventilate the area at the arc to keep fumes and gases away from the breathing zone. If ventilation is not good, wear an approved air-supplied respirator.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator.
- Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Always use enough ventilation, especially in confined areas, to insure breathing air is safe.



Welding and cutting sparks can cause fire or explosion

- When not welding, make sure the electrode circuit is not touching the work or ground. Accidental contact can cause sparks, explosion, overheating, or fire. Make sure the area is safe before doing any welding.
- Welding and cutting on closed containers, such as tanks, drums, or containers, can cause them to blow up. Make sure proper steps have been taken.
- When pressure gas is used at the work site, special precautions are required to prevent hazardous situations.
- Connect work cable to the work as close to the welding zone as practical to prevent welding current from passing too long and creating fire hazards or overheat.
- Wear oil-free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap. Wear ear plugs when welding out of position or in confined places. Always wear safety glasses with side shields when in a welding area.
- Be attention that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas and start a fire. Remove fire hazardous from the welding area, if not possible, cover them thoroughly. Do not weld where flying sparks can strike flammable material and where the atmosphere may contain flammable dust, gas, or liquid vapors (such as gasoline).
- Protect yourself and others from flying sparks and hot metal. Remove any combustibles from operator before perform any welding.
- Keep a fire extinguisher readily available.
- Empty containers, tanks, drums, or pipes which have combustibles before perform welding.
- Remove stick electrode from electrode holder or cut off welding wire at contact tip when not in use.
- Apply correct fuses or circuit breakers. Do not oversize or bypass them.



Cylinder can explode if damaged

- Pressure gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.
- Cylinders should be located away from areas where they may be struck or subjected to physical damage. Use proper equipment, procedures, and sufficient number of persons to lift and move cylinders.
- Always install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling over or tipping.
- Keep a safe distance from arc welding or cutting operations and any other source of heat, sparks, or flame.
- No touching cylinder by welding electrode, electrode holder or any other electrically "hot" parts. Do not drape welding cables or welding torches over a gas cylinder.
- Use only correct compressed gas cylinders, regulators, hoses, and fittings designed for the process used; maintain them and associated parts in good condition.
- Use only compressed gas cylinders containing the correct shielding gas for the and properly operating regulators designed for the gas and pressure used. All hoses, fittings, etc. should be suitable for the application and maintained in good condition.
- Open the cylinder valve slowly and keep your head and face away from the cylinder valve outlet.
- Valve protection caps should be kept in place over valve except when the cylinder is in use or connected for use.



Hot parts can burn

- Do not touch hot parts with bare hand or skin.
- Ensure equipment is cooled down before perform any work.
- If touching hot parts is needed, use proper tools and/or wear heavy, insulated welding gloves and

clothing to prevent burns.



Flying metal or dirt can injure eyes

- When welding, chipping, wire brushing, and grinding can cause sparks and flying metal. It can hurt your eyes.
- Remember wear appropriate safety glasses with side shields when in welding zone, even under your welding helmet.




Noise can damage hearing

- Noise from some processes or equipment can damage hearing.
- Remember wear approved ear protection to protect ears if noise level is high.



Moving parts can injure

- Stay away from moving parts such as fans.
- Stay away from pinch points such as drive rolls.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Have only qualified persons remove doors, panels, covers, or guards for servicing and maintenance.
- Reinstall doors, panels, covers, or guards when servicing and maintenance is finished and before reconnecting input power.



Overuse can cause overheating

- Use machine follow duty cycle. Reduce current or reduce duty cycle before starting to weld again.
- Allow cooling period.
- Do not block or filter airflow to unit.



Static can damage PCB

- Always wear wrist straps before touching PCB or parts.
- Use proper static-proof bags and package to store or move PCB.



Safety markings

- Equipment with CE-markings fulfils the basic requirements of the Low-Voltage and Electromagnetic Compatibility Guideline (e.g. relevant product standards according to EN 60974.1).



Safety markings

- The equipment with the CCC mark meets the basic requirements stipulated in the Chinese standards GB / T15579.1-2013 and GB / T8118.



Safety markings

- This marking means that the product is certified for both the U.S. and Canadian markets, to the applicable U.S. and Canadian standards. The preferred location of the indicators is as shown.

Contents

1-GENERAL REMARKS	6
1-1 Power source features	6
1-2 Functional principle	6
1-3 Output characteristics	6
1-4 Duty cycle	7
1-5 Applications.....	7
1-6 Warning label	8
2-VERSIONS BRIEFS.....	8
3-BEFORE COMMISSIONING.....	9
3-1 Utilization for intended purpose only	9
3-2 Machine installation rules.....	9
3-3 Power source connection.....	9
3-4 Welding cables instruction	9
4-PoWer TIG 3201 AC/DC Pulse	11
4-1 System components	11
4-2 Basic equipments for welding	11
4-3 Control panel.....	11
4-4 Submenu.....	17
4-5 Other function	17
4-6 Interface	20
4-7 Installation.....	22
4-8 Technical data.....	25
4-9 Dimension	25
4-10 DISASSEMBLY AND REASSEMBLY	26
5-REMOTE CONTROLLER	29
5-1 Analog remote controller.....	29
5-2 Digital remote controller.....	29
6-TROUBLE SHOOTING	31
7-CARE AND MAINTENANCE.....	32

1-GENERAL REMARKS

1-1 Power source features

This series TIG welding machine can perform DC TIG, Pulse TIG, AC TIG, AC pulse TIG and SMAW processes. This series welding machines enjoy reasonable static characteristic and sound dynamic characteristic..

Features and benefits:

- MCU controlled technology
- Self-diagnostic function with error code display
- AC square wave and sine wave waveform output
- 30 sets of parameters can be stored
- Pre-gas, post-gas, up-slope time, down-slope time, adjustable parameters, easy to control
- Pulse frequency, pulse ratio, pulse width can be adjusted to improve the welding performance
- By adjusting the pulse current, pulse frequency, pulse width, AC current, AC frequency, cleaning ratio and AC offset ratio, the required penetration depth, penetration width and ripple number of the weld can be obtained, and the life of the tungsten electrode can be extended.
- Remote controller or foot pedal is optional.

1-2 Functional principle

This series welding machines apply IGBT HF inverter technology. 3- phase input volt is rectified, then transformed into HF AC by the inverter which includes IGBT, etc., reduced by HF transformer, rectified and filtered by HF rectifier, Then the secondary inverter outputs adjustable low-frequency AC square wave current, then output. After this process, the welding machine dynamic response ability has been greatly improved, size and weight of transformer and reactor are reduced noticeably, and whole machine efficiency has been improved.

The design of control circuit makes the welding machine enjoy strong ability against power grid fluctuation and perfect welding performance. Welding machine has the following features: easy arc-starting, stable arc, good welding seam formation and capability of continuous welding current regulation. The schematic diagram is as shown in Fig. 1-2-1:




Fig. 1-2-1: Schematic diagram

1-3 Output characteristics




Fig. 1-3-1: Output characteristics

1-4 Duty cycle

Duty cycle is percentage of 10 minutes that a machine can weld at rated load without overheating. If overheats, thermostat(s) will open, output stops. Wait for fifteen minutes for the machine to cool down. Reduce amperage or duty cycle before welding.

 **Note!** Exceeding duty cycle can damage the machine and greatly reduce its lifespan.




Fig. 1-4-1: Duty cycle

1-5 Applications


This series of machines have many welding processes and can weld most of the metal materials, including carbon steel, stainless steel, copper, titanium, aluminium and Al-Mg alloy etc.

Recommended areas of use are as follows:

- Boiler and container manufacture
- Aerospace industry
- Chemical structure and engineering
- Electric power construction
- Shipbuilding and offshore engineering
- Automobile
- Vehicle manufacture
- Mechanical industry
- Others

1-6 Warning label

The warning label is affixed on the top of machine.





 DANGEROUS!  WARNING!		DO NOT REMOVE THIS MARKING	
 <ul style="list-style-type: none"> ● ELECTRIC SHOCK can kill. ● Keep the welder and work piece in good grounding. 		 <ul style="list-style-type: none"> ● GASES AND FUMES can be dangerous & hazardous to your health. ● Keep adequate ventilation, anti-dust and exhaust. ● Keep your head out of the fumes. 	
 <ul style="list-style-type: none"> ● ARC RAYS, Spatter can injure eyes and skins. ● NOISE can cause permanent hearing loss. ● Wear protective clothing and welding shield with filter. 		 <ul style="list-style-type: none"> ● FIRE, EXPLOSION can be caused by hot slag, spatter and sparks. ● Remove combustibles from working area. ● Provide fire watch as well as fire appliance in the working area. 	

Fig. 1-6-1: Warning label

2-VERSIONS BRIEFS

Professional welding of special materials requires special welding parameters. Different models of the power sources are matched to different weldings.

This fully digitized power sources have logically arranged control panel for convenient operation, which can perform SMAW, DC TIG, DC Pulse TIG, AC TIG and AC Pulse TIG. It can use the foot pedal to adjust the current.

3-BEFORE COMMISSIONING



Warning! Operating the equipment incorrectly can cause serious injury and damage. Do not use the functions described here until you have read and completely understood "safety rules".

3-1 Utilization for intended purpose only

The power source may only be used for SMAW ,TIG. Utilization for other purposes, or in any other manner, shall be deemed to be "not in accordance with the intended purpose". The manufacturer shall not be liable for any damage resulting from such improper use. Operate, inspect and maintain should follow all the instructions given in this manual.

3-2 Machine installation rules

According to test, protection degree of this power source is IP21S(IP23S optional). However, the internal key components must be protected from direct soaking.



Warning! A machine that topples over or falls from its stand can cause injury. Place equipment on an even, firm floor in such a way that it stands firmly.

The venting duct is very important for safety protections. When choosing the machine location, make sure it is possible for the cooling air to freely enter and exit through the louvers on the front and back of machine. Any electro conductive metallic dust like drillings must not be allowed to get sucked into the machine.

3-3 Power source connection

- The power source is designed to run on the voltage given on the nameplate.
- The mains cables and plugs must be mounted in accordance with the relevant technical standards.
- The power supply sockets that come with power source are designed to use strictly according to the marked voltages.



Note!In adequately dimensioned electrical installations can lead to serious damage. The mains lead, and its fuse protection, must be dimensioned in accordance with the local power supply. The technical data shown on the name plate shall apply.

3-4 Welding cables instruction

When welding, please pay attention to the followings:

- a. The welding cables should be kept as short as possible;
- b. If extended cable is used, please do as shown in Fig. 3-4-1.

<p>Wrong</p> <p>Coil the excess ground cable and welding cable in same direction respectively.</p>	
<p>Correct</p> <p>Straighten the ground cable and welding cable and make them close to each other.</p> <p>Bundle the ground cable and welding cable together, running the wires close to the ground.</p>	




Fig. 3-4-1: Welding cables instruction

4-PoWer TIG 3201 AC/DC Pulse

4-1 System components

Welding machine can be equipped with many different accessories and can be used in different special sites with different configurations.




Fig. 4-1-1: System components

4-2 Basic equipments for welding

Only be equipped with the necessary accessories, can the power source Power TIG 3201 AC/DC Pulse operate well. The following is the needed accessories list.

TIG welding

- Power source
- Water cooling machine
- Ground cable
- TIG welding torch
- Gas regulator, gas hose, gas cylinder (to supply the machine with shielding gas)
- Welding wire

STICK welding

- Power source
- Ground cable
- Electrode holder
- Electrode

4-3 Control panel



Note! You may find that your machine has certain functions or some parameters that are not described in this operating manual. Also, certain illustrations may be very slightly different from the actual controls on your machine.

However, these controls function in exactly the same way.




Fig. 4-3-1: Control panel

1. Left displayer

Used for displaying the welding current, voltage and other parameters. If different parameters are selected, the relevant indicator will light up.

2. Right displayer

Used for displaying the welding current, frequency and other parameters. If different parameters are selected, the relevant indicator will light up.

3. Torch operation button

In TIG mode, press this button to switch 2-STEP, 4-STEP, repeat and spot welding operation mode, the indicator will light up accordingly.

Torch operation mode:

Legend:




Fig. 4-3-2: Press torch trigger




Fig. 4-3-3: Hold torch trigger




Fig. 4-3-4: Release torch trigger

2-STEP operation mode




Fig. 4-3-5: 2-STEP operation mode

4-STEP operation mode




Fig. 4-3-6: 4-STEP operation mode

Repeat operation mode




Fig. 4-3-7: Repeat operation mode

Spot welding operation mode




Fig. 4-3-8: Repeat operation mode

4.AC/DC and pulse button

Press this button to switch AC TIG, DC TIG, DC PULSE TIG and AC PULSE TIG mode, the indicator will light up accordingly.

5.TIG/MMA button

Press the button to switch between TIG and MMA, the indicator for the selected progress will light up.

6.Welding parameters:




Fig. 4-3-9: Parameters

Parameters	Description	Unit	Setting range	Factory setting
PRE GAS	Time of gas flow before welding	Sec	OFF~10.0	0.2
START	The initial current after the arc is started	A	4~315	50
UP-SLOPE	Time of starting current is increased until it reaches welding current	Sec	OFF~10.0	0.1
CURRENT	Welding current while in the SMAW and DC TIG mode	A	4~320	100
CLEAR RATIO	Time proportions of clean current in AC mode	%	-50~+40%	0
AC FREQUENCY	The frequency of welding current in AC mode	Hz	40-250	60
PEAK CURRENT	Welding current while in the DC Pulse TIG mode	A	4~320	100
DUTY CYCLE	The time proportion of peak current in single cycle under pulse mode	%	15-85	40
FREQUENCY	The frequency of welding current in pulse mode	Hz	DC:0.2~999 AC:0.2~250	4.0
BASE CURRENT	The arc maintenance current in pulse mode	A	4~320	20
DOWN-SLOPE	Time of welding current is continuously lowered until it reaches final current	Sec	OFF~15	0.4
STOP ARC	The current before arc blowout	A	4~315	50
POST GAS	Time of gas flow after arc blowout	Sec	OFF~60	15.0

Table. 4-3-1: Parameter list

7.ADJUSTMENT knob

In TIG mode, it is used for adjusting the parameters that are described in 6. When a parameter is selected by SELECTION knob, rotate this knob clockwise to increase the selected parameter;rotate this knob anticlockwise to decrease the selected parameter. Press this button and turn to left or right for quick adjustment;

In SMAW mode, it is used for adjustment value of welding current.

8.SELECTION knob

In TIG mode, it is used for selecting the parameters that are described in 6. Rotate clockwise to select parameter from left to right; rotate anticlockwise to select parameter from right to left.

In SMAW mode, it is used for selecting arc force current (factory setting 20A,range 10-200A).

Important! Thanks to the microprocessor control, the following functions can be realized:

All parameters that have been set can be automatically stored and will retain until the next time they are changed. This is true even if the power source is switched off and on again in the meantime.

9.F/S button

Press the button to select fast or slow adjustment mode

Slow adjustment - Press the button and the indicator is light up to enter into slow adjustment mode, and all the parameters can be adjusted.

Fast adjustment - Press the button and the indicator is light off to enter into fast adjustment mode. The parameters can be adjusted by selection knob and adjustment knob. For adjustable parameters, please see below table, other parameters are sub-menu parameters and can't be adjusted.

Process	Parameter selection knob	Parameter adjustment knob
DC		CURRENT
DC pulse	DUTY CYCLE	PEAK CURRENT
AC	CLEAN RATIO	CURRENT
AC pulse	DUTY CYCLE	PEAK CURRENT
SMAW	ARC FORCE	CURRENT

Table 4-3-1: Fast adjustment

10.Fn/Gas test button

Press the button (release it within 5s) and the indicator lights up to enter into sub-menu interface; Press the button again(release it within 5s) and the indicator lights off to exit from sub-menu interface. Please refer to 4-4 submenu.

Press the button (for more than 5s) and release it to enter gas test, the gas valve starts to flow of shielding gas and stop automatically after 30s to exit from gas test. Press the button again within 30s to stop flow of shielding gas and exit from gas test.

11.AC waveform button

In AC TIG mode, press the button to select standard square wave, irregular square wave, sine wave, mixture wave or triangle wave, and the relevant indicator will light up.

Standard square wave-Responsive arc with fast zero crosses and reduced peak current. Stable arc with good puddle control and fast travel speed, Minimizes tungsten super heating.




Fig. 4-3-10: Standard square waveform

Irregular square wave: Stronger arc with slow zero crosses and lose noise; the strongest arc and deep penetration, less noise.




Fig. 4-3-11: Irregular square wave

Sine wave-Traditional smooth shaped waveform. Soft arc and less noise. Good for wide seam.




Fig. 4-3-12: Sine waveform

Triangle wave: Minimized area (heat) under the curve shape with high peaks. Lower amperages can minimize heat input to the weld High peaks more forceful for anodized applications.




Fig. 7-3-13: Triangle wave

Mixture wave: Alternate output AC current and DC current, high Efficiency. (Fig. 7-3-14)




Fig.4-3-14: Mixture wave

4-4 Submenu

4-4-1 Submenu parameter

Process	Sub-menu Parameter	Code	Setting range	Default value
TIG	Tungsten electrode diameter	ELd	0.8~6.0(mm)	2.0mm
	AC waveform	nSt	0-1	0
	Water cooling	H2O	ON OFF	ON
	Channel selection	CHA	n0~n29	n0
	HF selection	HF	on oFF	on
	Arc-start polarity(DC TIG mode)	P~S	PoS nEG	nEG
	Spot welding time	SPT	OFF~10.0(s)	0.1s
SMAW	Hot start current	HCu	20~200(A)	50A
	Hot start time	Hti	0.1~2.0(s)	0.5s
	Knee point voltage	Uln	15~30(V)	15V
Timing function	t-L	0000:00~	000	
	t-H	9999:59	000	
Factory setting	FAC	no YES	YES	

Table. 4-4-1: parameters list

4-4-2 Enter and exit submenu

Press the Fn button (release it within 5s) and the indicator lights up to enter into sub-menu interface; Press the Fn button again (release it within 5s) and the indicator lights off to exit from sub-menu interface. Select parameter code by selection knob, adjustment parameter value by adjustment knob.




Fig. 4-4-1: Submenu operation

4-5 Save and Call (Submenu-Channel parameter)

The welders need to write down technical parameters for some repeated jobs. Thanks to this function, up to 30 job records can be stored and loaded.

Save a job

- Set the parameter to be stored;
- Press Fn key (release it within 5s) and the indicator lights up to enter into sub-menu interface;
- Select code "CHA" by selection knob, Select channel No "n0~n29" by adjustment knob;
- Press AC/DC button for 3s and the channel No is changed from "n0~n29" to "P0~P29", meaning the present job parameter has been stored;
- Press AC/DC button again (release it within 5s) and the indicator lights off to exit from the sub-menu parameter adjustment, the job creation is completed.




Fig. 4-5-1: Save operation

Call a job

- Press Fn key (release it within 5s) and the indicator lights up to enter into sub-menu interface;
- Select code "CHA" by selection knob, Select channel No "P0~P29" by adjustment knob;
- Press 2-STEP/4-STEP button and Ch indicator lights up, meaning the job parameter which stored in present channel is loaded. At this time, the knobs and buttons on the panel are locked and the present parameters can't be changed.
- Press 2-STEP/4-STEP button again (release it within 5s) and the indicator lights off to exit from job loading; the present job parameters can be used for welding and the job loading is completed;
- In call mode, press 2-STEP/4-STEP button again and Ch indicator lights off, cancel the present call state and the panel is unlocked.




Fig. 4-5-2: Call operation

Delete a job

- Press Fn key (release it within 5s) and the indicator lights up to enter into sub-menu interface;
- Select code "CHA" by selection knob, Select channel No "P0~P29" by adjustment knob;
- Press TIG/MMA button for 5s, the channel No is changed from "P0~P29" to "n0~ n29", meaning the job parameter which is stored in present channel is deleted;
- Press Fn key (again (release within 5s) and the indicator lights off to exit from "delete job", the job deletion is completed.




Fig. 4-5-3:Delete operation

4-6 Other function

4-6-1 Timer reset

- Press Fn key (release with 5s) and the indicator lights up to enter into sub-menu interface;
- Select code "t-L" or "t-H" by selection knob to check specific value. "t-L" indicates the low-order value and "t-H" indicates the high-order value. Combine both values to read the timing time;
- If you want to zero clearing the time, press TIG/MMA button for 3s and the value becomes zero;
- Press Fn key again (release it within 5s) and the indicator lights off to exit from timing function.

Example: If the high-order and low-order are shown as Fig. 4-6-1, meaning the timing time is 9933.20, it is nine thousand nine hundred and thirty-three hours and twenty minutes.




Fig. 4-6-1:Timer Reset

4-6-2 Reset to factory setting

- Press Fn key (release with 5s) and the indicator lights up to enter into sub-menu interface;
- Select code "Fac" by selection knob
- Press TIG/MMA button for 3s and "YES" appears on right-hand displayer, the factory setting is restored.
- Press Fn key again (release within 5s) and the indicator lights off to exit from factory setting, and the factory setting is completed.




Fig. 4-5-2: Reset to factory setting

4-7 Interface

Note! You may find that your machine has certain functions or some parameters that are not described in this operating manual. Also, certain illustrations may be very slightly different from the actual controls on your machine. However, these controls function in exactly the same way.




Fig. 4-7-1: Front panel




Fig. 4-7-2: Rear panel

1. Output terminal (+)

Connect electrode holder when in SMAW mode; Connect with the workpiece when in TIG mode.

2. Control socket

Connect to torch trigger or foot pedal.


	Pin No.	Description	Pin No.	Description
	1	Torch trigger	4	10VDC
	2	Torch trigger	5	Remote preset current signal
	3	Remote enable(low level)	6	GND

Table. 4-7-1 Description of remote control socket

3.Output terminal (-)

Connect work piece when processing SMAW; connect with TIG torch when processing TIG welding.

4.Water inlet

Connect water hose of TIG torch.(optional).

5.Gas outlet

Connect gas hose of TIG torch.

6.Analog control socket (**Optional**)

Connect to analog remote controller or other special device.

Pin No.	Description
1	Chassis Ground , connect with shield layer of control cable.
2	Null
3	Power supply of remote control current given potentiometer:10VDC
4	Remote control current input signal (0-10VDC).
5	Remote control current GND.
6	Welding machine start signal, short circuit with pin 8 ,welding machine start
7	Gas test signal, short circuit with pin 8,the gas valve on.
8	Gnd.
9	Arc voltage output,0-10VDC(10V equals to 100V arc voltage).
10	Welding current output signal,0-10VDC(10V equals to Max. rated output current).
11	Gnd
12	Successful arc start signal: Standby: pin 12 and pin 13 is normal open, successful arc start: pin12 and pin13 short circuit
13	

Table. 4-7-2 Description of analog control socket

7.Digital remote control socket (**Optional**)

Connect to digital remote controller or other 485 communication device.


	Symbol	Pin No.	Description	Pin No.	Description
		1	38VAC	4	B
		2	38VAC	5	Y
		3	A	6	Z

Table. 4-7-3 Description of digital remote control socket

Connect another welding machine to realize synergic welding .


	Pin No.	Pin No.	Description	
		1	The machine sends a signal to the slave	Transmit signal 1
		2		Transmit signal 2
		3	Receive signal from slave	Recive signal 1
		4		Recive signal 2
		5	Command ground	Command ground

Table. 4-7-4 Description of socket

8.Fan

Cooling down the heating components in the welding machine.

9. Water outlet

10 Gas inlet (part of solenoid valve)

Connect with Argon gas regulator with gas hose.

11.Nameplate

12.Fuse

13.Circuit breaker

The function of circuit breaker is to protect welding machine and operator by automatic trip to turn-off power supply when overload or short circuit happens to the power source. Normally, the switch flipped to upward means power-on. To start or stop the welding machine is done by the mains switch in the distribution box. Please do not take this circuit breaker as the power switch.

14.Power cord

It is 4-pin cable. The mixed-colored wire must be firmly grounded, the rest wires are connected with corresponding 3-phase power supply.

4-8 Installation

● Installation environment requirements


1. It should be placed indoors without direct sunlight, rainproof, low humidity and less dust. The ambient air temperature range is -10°C~+40°C.
2. The inclination to the ground should not exceed 10°.
3. There should be no wind in the welding station, if any, it should be covered.
4. The welding machine is more than 20cm away from the wall, and the distance between the welding machine is more than 10cm.
5. When using water-cooled welding torch, pay attention to anti-freezing.

● power supply and cable requirement

Please note the size of fuse and circuit breaker in the table below are for reference only.

Model		PoWer TIG 3201 AC/DC Pulse
Input power supply		3 phase, AC380/400/415V±10%, 50Hz
Electricity grid min. power (KVA)	Power grid	14
	Generator	20
Input protection(A)	Fuse	20
	Circuit breaker	63
Cable size (mm ²)	power cord	≥2.5
	Output cable	35
	Protective GND wire	≥2.5

Table 4-8-1: Power supply and cable requirement

 **Note!** Welding machine must be taken special design if it is powered by generator, please contact with manufacturer if you have such needs.

connections of power cord and distribution box



Warning! -Avoid hot-line work

- Operating by professional electrician
- Avoid connecting two power sources to one breaker
- Please refer to Table 6-1 to check if standard of input voltage, breaker and input cable is suitable





Fig.4-8-1: Connections of power cord and distribution box

●Gas cylinder installation



1. Stand the gas cylinder on the trolley and secure it by fixing the cylinder strap around a point in the top third of the cylinder-but never around the neck of the cylinder.
2. Take the protective cap off the gas cylinder.
3. Gently turn the gas-cylinder value anticlock wise, and blow off any dust and dirt.
4. Screw the pressure regulator onto the gas cylinder and tighten it.
5. Connect the shielding-gas connector to the pressure regulator.

Fig. 4-8-2: Gas cylinder installation

●TIG welding(gas cooling)



Warning! Operating the machine incorrectly can cause serious injury and damage. Do not use the machine until you have read the following

- Safety rules
- Before putting the machine into service



Warning! If the machine is plugged into the mains supply and the mains switch is in "O" position during preparation, there is a high risk of very serious injury and damage. Only carry out preparation when the machine is unplugged from the mains and the mains switch is off.




Fig.4-8-3: Connection and operation for gas-cooling TIG welding

●TIG welding(water cooling)




Fig. 4-8-4: Connection and operation for water-cooling TIG welding(Combined one machine)




Fig. 4-8-5: Connection and operation for water-cooling TIG welding (Separate water cooling machine)

●SMAW welding




Fig.4-8-6: Connection and operation for SMAW welding

4-9 Technical data



Note! For machines designed for special voltages, below is the technical data on the name plate.

Model	PoWer TIG 3201 AC/DC Pulse	
Input voltage/frequency(3 phase)	, AC380V/400/415V, 50Hz	, AC220~440V, 50/60Hz
Rated input capacity (KW)	14	14
Rated input current (A)	21/20/19	25/20/18
Output current adjustment range (A)	4~320	
Duty Cycle (%)	60	
OCV (V)	79(TIG)/45(MMA)	79(TIG)/45(MMA)
Weight (Kg)	40	42
Insulation class	H	
Tungsten diameter(mm)	1~5	
Electrode diameter(mm)	2~5	

Table 4-9-1 Technical data

4-10 Dimension




Fig. 4-10-1: Dimension

NO.	Item	Unit(mm)	Unit(inches)
1	length	670	26.4
2	Width	330	13
3	Height	572	22.5

Table. 4-10-1: Dimension

4-11 Disassembly and reassembly




Fig.4-11-1: DRAWING

NO.	Item	Stock NO.	Qty	REMARKS
1	Quick socket	740002-00026	2	
2	Control socket	740003-00047	1	
3	Breathing copper mouth	766001-00095	1	
4	Knob	730031-00074	2	
5	Filter	752004-00017	1	CE standard
6	Control panel sticker	771001-01951	1	
7	Plastic front panel	262005-01040	1	
8	Front panel	262035-01039	1	
9	Display board	220503-00175	1	
10	Left side panel	--	1	COLOR
11	Charging inductance assembly	220095-00001	1	
12	Main transformer	220629-00018	1	
13	Isolation transformer	763003-00023	1	
14	Resonant inductance	220521-00006	1	
15	Resonant capacitor	722001-00073	1	
16	Current Transformer	220149-00028	1	
17	Anti-co-template components	210250-00002	1	
18	Protection board parts	210020-00011	1	
19	Main control board	210580-00111	1	
20	Power Board	210100-00002	1	
21	Power Transformers	763001-00041	1	
22	Transformer bracket	766003-00019	1	
23	Driver board	210310-00096	1	
24	Handle	766003-02388	2	
25	Top cover	--	1	COLOR
26	Fan	746001-00017	1	
27	Circuit breaker pressure plate	766003-00188	1	
28	Circuit breaker	745011-00022	1	
29	Back panel	262011-00738	1	
30	Circuit breaker cover	766003-02217	1	
31	Waterproof cable clamp	773002-00009	1	
32	Fuse holder	740007-00004	1	
33	Button plug	773007-00005	1	
34	Fan cover	766003-02403	1	
35	Electromagnetic valve	752001-00014	1	
36	Right side panel	--	1	COLOR
37	Bottom plate	263065-00447	1	
38	Polypropylene capacitor	722001-00070	2	
39	Input capacitor bracket	766002-00104	1	
40	Step-up transformer	220431-00051	1	
41	Rack Capacitor Board	220293-00023	1	
42	High frequency box	766003-00114	1	
43	Arc ignition plate assembly	220575-00003	1	

44	High leakage transformer	763003-00018	1	
45	Output reactor	763004-00112	1	
46	Copper and aluminum joints	740016-00017	1	
47	current sensor	220125-00023	1	
48	Wire wound resistor 200W/20 Ω	720006-00034	2	
49	Wire wound resistor 50W/30 Ω	720005-00028	1	
50	Charging rectifier board	220089-00004	1	
51	Secondary IGBT absorption board	220215-00001	1	
53	Diode connection copper bar 1	766001-00228	1	
54	Current sensor connection copper bar 1	766001-00020	1	
55	DC bus output connection copper bar	766001-00165	1	
56	Diode protection board	220233-00004	2	
57	Diode connection copper bar 4	766001-00072	1	
58	Diode connection copper bar 2	766001-00063	1	
59	Diode connection copper bar 3	766001-00070	1	
60	Secondary IGBT components	220221-00001	2	
61	Fast recovery diode module	735006-00056	1	
62	Fast recovery diode module	735006-00055	2	
63	Output diode radiator	264011-00034	1	
64	IGBT radiator	264005-00020	1	
65	Radiator bracket	766002-00091	1	
66	Exchange current inductance	220281-00008	1	
67	Radiator connecting plate	775004-00087	1	
68	Radiator support frame	766002-00080	2	
69	Temperature relay	745008-00006	1	
70	IGBTmodule	735007-00046	2	
71	IGBT protection board	220005-00149	1	
72	Polypropylene capacitor	722001-00067	1	
73	Three-phase rectifier module	735005-00010	1	
74	Varistor	720021-00017	1	

Table.4-11-1: spare parts

5-REMOTE CONTROLLER

5-1 Analog remote controller

The analog remote controller can only adjust the welding current, suitable for ATIG***PAC welding machine.




Fig.5-2-1-1:Analog remote controller

5-2 Digital remote controller




Fig.5-2-1-1: Digital remote controller

5-2-1 Control panel




Fig.5-2-2-1: control panel

Please refer to chapter 4-3 of the control panel of the welding machine.

5-2-2 Interface

Connect to welding machine.

Pin No.	Pin No.	Description
	1	38VAC
	2	38VAC
	3	Y
	4	Z
	5	A
	6	B
	7	Null

Table 5-2-2-1 Description of control socket

5-2-3 Spare parts




Fig.5-2-3-1:Spare parts

No.	Item	Stock No.	Qty	Remarks
1	Display board	220503-00071	1	
2	Control socket	740001-00034	1	
3	Control plug(7pin)	740001-00002	1	
4	Control plug(6pin)	740003-00004	1	
5	knob		2	
6	PC sticker		1	

Table.5-2-3-1 Description of control socket

6-TROUBLE SHOOTING



Warning! An electric shock can be fatal. Before opening the machine:

- Switch it off and unplug it from the mains
- Unplug machine from the mains
- Put up a clearly legible and easy-to-understand warning sign to stop anybody inadvertently switching it back on again
- Check to make sure the electrically charged components (e.g.capacitors) have been discharged.
- Bolt in outer case also works for ground connection. Never use other bolt, which can not work for ground connection.

Machine problem, cause and remedy



Note! The following troubles and causes are uncertain. However, during the process of ATIG-P series and the normal using conditions, these might happen.

No.	FAULT	CAUSE	REMEDY
01	Indicator light does not light on and welding machine doesn't work when machine switches on	Default phase	Check power source
		Fuse (2A) is broken	Check whether the fan, power transformer and control board are in good condition
		Wire disconnection	Check and repair
02	Circuit breaker trips automatically except working for a long time in high welding current	IGBT module, three phase rectifier, or output diode module is damaged	Check and replace
		Short circuit	Check and replace
03	Welding current is not stable	Default phase	Check power supply
		Main control board is damaged	Check and replace main control board
04	The welding current is not adjustable	Inner line is broken	Check and replace
		Main control board is damaged	

Table 6-1: Trouble shooting

● Error code display

This series of machines have automatic protection and error code display function. Relevant Cause & Remedy can be found according to below Error codes, as shown in Table 6-2

Code	Trouble	Cause	Remedy
E1E	Over voltage	1. The secondary IGBT is damaged 2. The main control board is damaged	Check and replace
E10	Torch trigger fault	No current output after pressing torch trigger for 2s	Release torch trigger
E19	Over-heat protection	The welding machine is over heat; Temperature Relay fault Main control board damaged	Shut down the welding machine and wait for cooling; or replace Temperature Relay
E0A	Water-cooling is abnormal	No circulating water in water cooling system Water flow sensor damaged	Check and repair
E40	Communcation is abnormal	1.The communication harness is loose or disconnected 2.The main control board is faulty 3.Display board failure	Check and replace

Table 6-2: Displayed error code

7-CARE AND MAINTENANCE

Before open the machine



Warning! An electric shock can be fatal. Before opening the machine:

- Switch it off and unplug it from the mains
- Put up a clearly legible and easy-to-understand warning sign to stop anybody inadvertently switching it back on again
- Check to make sure the electrically charged components (e.g.capacitors) have been discharged
- Bolts in outer case also work for ground connection. Never use other bolt that can not work for ground connection

Maintenance of welding power source

Please follow the instructions as below to ensure normal use of power source

- Conduct safety check at regular intervals (see "Safety rules")
- Dismantle machine side panels and clean machine inside with clean and low-pressure compressed air by professional technician, not less than twice per year. Clean the components at a certain distance only
- If a lot of dust has accumulated, clean the cooling-air ducts

Maintenance of water-cooled welding torch

For water cooled welding torch:

- Check the connections of water cooling system
- Check the coolant level, cleanliness of coolant etc. (clean coolant only)
- Frequently check coolant's back flow state

Daily maintenance

			Disconnect main power before maintenance		
	3 months				
Change illegible label			Repair or replace broken cable		Clean and tighten welding terminal
	6 months				
Blow or suck inner part, and clean every month when working in harsh environmental conditions		OR			

Fig.7-1: Daily maintenance

Power TIG Series



GeKaMac[®]



Gedik Welding Inc.

Ankara Caddesi No: 306 Şeyhli 34906 Pendik - İstanbul / Turkey

P. +90 216 378 50 00 • **F.** +90 216 378 20 44

www.gedikwelding.com