

PoWer Plus+ Series



GeKaMac[®]



PoWer Plus+ CUT 65 **Manual Instructions**

Please Read and Understand This Manual
Before Operating The Welding Machine

www.gedikwelding.com



Attention!

Our Valued Customer,

We kindly request that you obey the warnings mentioned below:

- Definitely have the “Warranty Document” approved when you get the machine.
- Use the machine in a way that is in accordance with the fundamentals that are mentioned in the user’s guide of the machine.
- Refer to the nearest GEDIK WELDING authorized service or the service center of GEDIK WELDING when a problem comes up.

Thank you for preferring one of GeKaMac® products.

INDEX

	Page
1. Safety Rules.....	3
2. Working Principle of Main Circuit	5
3. Technical Parameters.....	5
4. Features of PoWer Plus+CUT 65	6
5. Installation	7
6. Layout of the Front and Rear Panel.....	8
7. Cutting Operation.....	9
8. Basic Troubleshooting Guide	9
9. Electrical Principle Drawing.....	11
10. Warranty Conditions.....	12
11. Warranty Document.....	13

1. SAFETY RULES

Important Safety Precautions

OPERATION AND MAINTENANCE OF PLASMA ARC EQUIPMENT CAN BE DANGEROUS TO YOUR HEALTH.

- Plasma arc cutting produces intense electric and magnetic emissions that may interfere with the proper function of cardiac pacemakers, hearing aids, or other electronic health equipment. Persons who work near plasma arc cutting applications should consult their medical health qualified technician and the manufacturer of the health equipment to determine whether a hazard exists.
- To prevent possible injury, read, understand and follow all warnings, safety precautions and instructions before using the equipment.



GASES AND FUMES

Gases and fumes produced during the plasma cutting process can be dangerous and hazardous to your health.

- Keep all fumes and gases from the breathing area. Keep your head out of the cutting fume plume.
- Use an air-supplied respirator if ventilation is not adequate to remove all fumes and gases.
- The kinds of fumes and gases from the plasma arc depend on the kind of metal being used, coatings on the metal, and the different processes. You must be very careful when cutting or cutting any metals which may contain one or more of the following:

Always read the Material Safety Data Sheets (MSDS) that should be supplied with the material you are using.

These MSDSs will give you the information regarding the kind and amount of fumes and gases that may be dangerous to your health.

- Use special equipment, such as water or down draft cutting tables, to capture fumes and gases.
- Do not use the plasma torch in an area where combustible or explosive gases or materials are located.
- Phosgene, a toxic gas, is generated from the vapors of chlorinated solvents and cleansers. Remove all sources of these vapors.



ELECTRIC SHOCK

Electric Shock can injure or kill. The plasma arc process uses and produces high voltage electrical energy. This electric energy can cause severe or fatal shock to the operator or others in the workplace.

- Never touch any parts that are electrically “live” or “hot.”
- Wear dry gloves and clothing. Insulate yourself from the work piece or other parts of circuit.

1. SAFETY RULES (Continuing)

- Repair or replace all worn or damaged parts.
- Extra care must be taken when the workplace is moist or damp.
- Disconnect power source before performing any service or repairs.
- Read and follow all the instructions in the Operating Manual.



FIRE AND EXPLOSION

Fire and explosion can be caused by hot slag, sparks, or the plasma arc.

- Be sure there is no combustible or flammable material in the workplace. Any material that cannot be removed must be protected.
- Ventilate all flammable or explosive vapors from the workplace.
- Do not cut or weld on containers that may have held combustibles.
- Provide a fire watch when working in an area where fire hazards may exist.
- Hydrogen gas may be formed and trapped under aluminum workpieces when they are cut underwater or while using a water table. DO NOT cut aluminum alloys underwater or on a water table unless the hydrogen gas can be eliminated or dissipated. Trapped hydrogen gas that is ignited will cause an explosion.



NOISE

Noise can cause permanent hearing loss. Plasma arc processes can cause noise levels to exceed safe limits.

You must protect your ears from loud noise to prevent permanent loss of hearing.

- To protect your hearing from loud noise, wear protective ear plugs and/or ear muffs. Protect others in the workplace.
- Noise levels should be measured to be sure the decibels (sound) do not exceed safe levels.



PLASMA ARC RAYS

Plasma Arc Rays can injure your eyes and burn your skin. The plasma arc process produces very bright ultra violet and infra red light. These arc rays will damage your eyes and burn your skin if you are not properly protected.

- To protect your eyes, always wear a cutting helmet or shield. Also always wear safety glasses with side shields, goggles or other protective eye wear.
- Wear cutting gloves and suitable clothing to protect your skin from the arc rays and sparks.
- Keep helmet and safety glasses in good condition. Replace lenses when cracked, chipped or dirty.
- Protect others in the work area from the arc rays. Use protective booths, screens or shields.

2. WORKING PRENCIPLE OF MAIN CIRCUIT

The working principle of CUT100 Air Plasma Cutting Machine is shown as the following figure. Three-phase 380V work frequency AC is rectified into DC (about 530V), then it is converted to medium frequency AC (about 20 KHz) by inverter device (discrete IGBT), after reducing voltage by medium transformer (the main transformer) and rectified by medium frequency rectifier (fast recovery diode), and is outputted by inductance filtering. The circuit adopts current feedback control technology to insure current output stably. Meanwhile, the cutting current parameter can be adjusted continuously and steplessly to meet with the requirements of cutting craft.




fig 2.1 Working principle diagram

3. TECHNICAL PARAMETERS

Models	PoWer Plus+CUT 65	
Parameters		
Rated input voltage (V)	3-380V±15%, 50/60Hz	
Rated input current (A)	17,4	
Rated input power (kW)	7,8	
Cutting current adjustment range (A)	20~65	
No-load voltage (V)	300	
Duty cycle (40°C 10minutes)	90% (65A)	
	100% (61A)	
The max. cutting thickness to Carbon steel (mm)	≤35	
Optimal cutting thickness (mm)	Carbon steel	≤25
	Stainless steel	≤25
	Aluminium	≤20
	Cuprum	≤14
Dimensions (mm)	640*240*445	
Protection class	IP23	
Insulation class	H	
Net weight (kg)	24	
Cooling method	AF	

Table2.1 Technical parameters

Note: The above parameters are subject to change with the improvement of machines.

4. FEATURES OF PoWer Plus+CUT 65

1. **IGBT parallel balanced current technology and digital control technology.**
2. **Wider input voltage flexibility** provides peak performance power under variable conditions ($\pm 15\%$) for steady cuts.
3. **EMI filter** restrains the EMI transmission of the power.
4. **Starts without high-frequency** so it will not interfere with controls or computers.
5. **Pilot Arc Controller** increases cutting capabilities and speeds, and improves tip life. So it can be applied to **cut netlike workpiece.**
6. **Various protective and alarm functions for pressure, tip, over-temperature and over-current** allow faster troubleshooting, eliminating unnecessary downtime.
7. **Back striking tip and electrode** ensure the velocity of striking and the quality of arc, and extend the life of them.

5. INSTALLATION

Use the packing lists to identify and account for each item.

1. Inspect each item for possible shipping damage. If damage is evident, contact your distributor and / or shipping company before proceeding with the installation.
2. When using forklift, its arm length must be long enough to reach the outside so as to ensure lifting safely.
3. The movement may bring the potential danger or substantive hazard, so please make sure that the machine is on the safe position before using.

Supply input connection of CUT100 power is shown as the Fig3.1.

1. Check your power source for correct voltage before plugging in or connecting the unit
2. Power Cord and Plug This power supply includes an input power cord and plug suitable for 380V AC 3 - Phase input power.
3. If the power supply voltage continually goes beyond the range of safe work voltage range, it will shorten the welder life-span. The following measures can be used:
 - Change the power supply input. Such as, connect the welder with the stable power supply voltage of distributor;
 - Reduce the machines using power supply in the same time;
 - Set the voltage stabilization device in the front of power cable input.

1. Connecting Gas Supply to Unit

Connect the gas line to the inlet port of the gas filter on the rear panel.

2. Check Air Quality

To test the quality of air, put the RUN / SET switch in the SET (down) position, check if there are any oil or moisture in the air.




Figure 3.1

6. LAYOUT OF THE FRONT AND REAR PANEL





Fig 4.1 schematic drawing of the front panel and rear panel

1. **Cutting current regulator:** it is used to regulate the current when cutting.
2. **Power pilot lamp**
3. **Alarm pilot lamp:** This pilot lamp indicates when lit that the protection of the machine has been activated.
4. **READY (DC Indicator):** Indicator is ON when DC output circuit is active.
5. **Cutting current regulator LED:** it is used to regulate the current when cutting.
6. **RUN/SET:** when cutting the workpiece, turn to the "RUN"; when doing gas test, turn to the "SET".
7. **Cutting gun connector:** connected to the cutting machine
8. **CNC Connection:** Connection with CNC plug.
9. **Positive output cable:** connected to the workpiece
10. **Barometer :** ensure there are no impurity and moisture in the compressed air
11. **Mains cable:** Connected to the appreciate power supply
12. **Power switch:** turn on or off the power source

7. CUTTING OPERATION



Note:

- 1) The alarm lamp on when cutting, it is needed to loose the switch of the torch until the alarm release, then press on the switch to restart working.
- 2) In the automatic gas test and examine, press on the cutting torch, there will no reflection.
- 3) After a long usage, the surface of the electrode and nozzle will have Oxidation reaction. Please replace the electrode and nozzle, For The alarm lamp will on when install the shield cup, and stop working

8. BASIC TROUBLESHOOTING GUIDE



WARNING

There are extremely dangerous voltage and power levels present inside this unit. Do not attempt to diagnose or repair unless you have had training in power electronics measurement and troubleshooting techniques.

A. Power lamp and temperature lamp on.

1. Air flow blocked, check for blocked air flow around the unit and correct condition.
2. Fan blocked, check and correct condition.
3. Unit is overheated, let unit cool down for at least 5 minutes. Make sure the unit has not been operated beyond Duty Cycle limit, refer to technology parameters in Section 2.
4. Faulty components in unit, return for repair or have qualified technician repair per Service Manual.

8. BASIC TROUBLESHOOTING GUIDE (Continuing)

B. Torch fails to ignite the arc when torch switch is activated

1. System is in SET mode, change to RUN mode.
2. Faulty torch parts, inspect torch parts and replace if necessary.
3. Gas pressure too high or too low, adjust to proper pressure.
4. Faulty components in unit, return for repair or have qualified technician repair per Service Manual.

C. No cutting output; Torch activated, power source on; Gas flows; Fan operates

1. Torch not properly connected to power supply, check that torch leads are properly connected to power supply.
2. Work cable not connected to work piece, or connection is poor, make sure that work cable has a proper connection to a clean, dry area of the workpiece.
3. Faulty components in unit, return for repair or have qualified technician repair per Service Manual.
4. Faulty Torch, return for repair or have qualified technician repair.

D. Low cutting output

1. Incorrect setting of CURRENT (A) control, check and adjust to proper setting.
2. Faulty components in unit, return for repair or have qualified technician repair.

E. Difficult Starting

1. Worn torch parts (consumables), shut off input power. Remove and inspect torch shield cup, tip and electrode. Replace electrode or tip if worn; replace shield cup if excessive spatter adheres to it.

F. Arc shuts off during operation; arc will not restart when torch switch is activated.

1. Power Supply is overheated, let unit cool down for at least 5 minutes. Make sure the unit has not been operated beyond Duty Cycle limit. Refer to Section 2 for duty cycle specifications.
2. Gas pressure too low, check source for at least 4bar/60psi; adjust as needed. It is need to open the machine cover.
- 3 Torch consumables worn, check torch shield cup, tip, starter element, and electrode; replace asneeded.
4. Faulty components in unit:, return for repair or have qualified technician repair per Service Manual.


G. No gas flow; the power lamp on; Fan operates

1. Gas not connected or pressure too low, check gas connections. Adjust gas pressure to proper setting.
2. Faulty components in unit, return for repair or have qualified technician repair.

H. Torch cuts but low quality

1. Current (A) control set too low, increase current setting.
2. Torch is being moved too fast across workpiece, reduce cutting speed.
3. Excessive oil or moisture in torch, hold torch 1/8 inch (3 mm) from clean surface while purging and observe oil or moisture buildup (do not activate torch). If there are contaminants in the gas, additional filtering may be needed.

9. ELECTRICAL PRINCIPLE DRAWING



- K: air-break switch
- EMC: EMC inductor
- F1: Power on board
- T: Power on board
- 2: primary winding
- Tr: main transformer
- D1, D2: fast recovery diode
- F1: fan
- QF: gas valve
- Hall: Hall current sensor
- main inductor
- T: current transformer
- 1: Positive output
- 3: control transformer
- M: pressure gauge

10. WARRANTY CONDITIONS

1. The length of the warranty starts on the date of delivery and it is for 1 year.
2. The whole merchandise including all its parts are covered by the warranty of our company.
3. If the merchandise breaks down within the length of the warranty, the time spent in the repair shop will be added to the length of the warranty. The length of repair of the merchandise is at the maximum 20 working days. This period of time starts on the date that the merchandise was delivered at one of the following locations: A service station or the seller of the merchandise or dealer or agency or representation office or importer or manufacturer, in this order if there are no service stations.
4. If the merchandise breaks down either due to material and workmanship or assembly lines within the length of the Warranty, it will be repaired without demanding any money under the name of expenditure of workmanship, the cost of the changed piece or under any other name.
5. Replacement operation will be done without charge in cases where the merchandise repeats the same fault more than twice or different faults come up more than four times within the length of the warranty, the length of the repair exceeds maximum necessary time and the determination of the unrepairability of the merchandise by a report that is prepared either by a service station or the seller or a dealer or an agency or a representation office or the importer or the manufacturer, in this order, if there are no service stations.
6. Faults that are results of misuse according to the user's guide of the merchandise are not covered by the warranty.
7. Ministry of Science Industry and Technology, The Protection of the Consumer and Competition General Directorate can be referred to whenever a problem concerning the warranty document comes up.
8. Earth clamp and plasma holder kits are not under warranty.

GeKaMac[®]

Gedik Welding Machines

Warranty Document

MACHINE INFORMATION

Brand : GeKaMac[®]

Model :

Serial Number :

CUSTOMER INFORMATION

Company Name :

Authorized Person :

Telephone :

Company Address :

City/Country.....

E-Mail :..... @.....

Signature /Cachet :

SERVICE INFORMATION

Authorized Service :

Service Staff :

Installation Date :/...../.....

Warranty Starting Date :

Warranty Expiration Date :

Signature /Cachet :

GeKaMac[®]

Gedik Welding Machines

Warranty Document

MACHINE INFORMATION

Brand : GeKaMac[®]

Model :

Serial Number :

CUSTOMER INFORMATION

Company Name :

Authorized Person :

Telephone :

Company Address :

City/Country.....

E-Mail :..... @.....

Signature /Cachet :

SERVICE INFORMATION

Authorized Service :

Service Staff :

Installation Date :/...../.....

Warranty Starting Date :

Warranty Expiration Date :

Signature /Cachet :

Manufacturer:

Company Name: Shanghai HI-ZONE Welding Equipment Manufacture Co.,Ltd.

Company adress: A-2nd Floor, No.99-3, Shenmei Road, Zhoupu, Pudong, Shanghai 201318
China

Contact Details: T: +86 21 31295500 | F: +86 21 51919711

Importer:

Gedik Kaynak San ve Tic A.Ş

Company Adress: Ankara Cad No: 306 Seyhli 34906 Pendik, Istanbul


TURKEY

Contact Details: +90 216 3785000

Power Plus+ Series



GeKaMac®



Gedik Welding — Ankara Caddesi
No : 306 Şeyhli 34906 Pendik, İstanbul / Turkey
T +90 216 378 50 00 F +90 216 378 20 44
gedik@gedik.com.tr